

USER MANUAL TABLE OF CONTENTS



GS1 AC DRIVES USER MANUAL

Warnings and Trademarks	W-1
~ WARNING ~	W-1
Trademarks.	W-1
~ AVERTISSEMENT ~	W-2
Marques de commerce	W-2
Warnings	W-3
GS1 User Manual Revision History	H-1
Chapter 1: Getting Started	1-1
Manual Overview	1-2
Overview of This Publication	1-2
Who Should Read This Manual	1-2
Supplemental Publications	1-2
Technical Support	1-2
Special Symbols	1-2
GS1 AC Drive Introduction	1-2
Purpose of AC Drives.	1-2
Selecting the Proper Drive Rating.	1-3
Nameplate Information	1-4
Model Explanation	1-4
Drive Package Contents	1-4
External Parts and Labels	1-5
GS1 AC Drive Specifications	1-6
GS1 Model-Specific Specifications	1-6
GS1 General Specifications	1-7

Chapter 2: Installation and Wiring	2-1
Ambient Conditions	2-2
Storage Conditions	2-2
Installation	2-3
Minimum Clearances and Air Flow	2-3
GS1 AC Drive Dimensions	2-4
GS1 Circuit Connections	2-5
Danger!	2-5
Wiring Notes: PLEASE READ PRIOR TO INSTALLATION.. . . .	2-5
Motor Operation Precautions	2-6
Short Circuit Withstand	2-6
Applicable Codes	2-6
Circuit Protection Devices	2-6
Maximum Recommended Circuit Protection Devices	2-6
Main Circuit Wiring	2-7
Input Power Connections	2-7
Output Power Connections	2-8
Control Terminal Wiring	2-8
Basic Wiring Diagram	2-9
External Wiring and Accessories	2-10
 Chapter 3: Keypad Operation and Quick-Start.	 3-1
The GS1 Digital Keypad	3-2
LED Display	3-2
Function Keys	3-2
Displaying the Status of the GS1 AC Drive	3-3
Programming the GS1 AC Drive	3-4
GS1 Quickstart	3-5
Example 1: Constant torque (e.g. conveyors, compressors, etc.)	3-5
Example 2: Variable torque (e.g. fans, centrifugal pumps, etc.)	3-8
 Chapter 4: AC Drive Parameters	 4-1
GS1 Parameter Summary	4-2
GS1 Detailed Parameter Listings	4-8
Explanation of Parameter Details Format	4-8
Motor Parameters	4-8
Ramp Parameters	4-9
Volts/Hertz Parameters	4-14
Digital Parameters	4-16
Analog Parameters	4-22
Analog Input Examples	4-24
Presets Parameters	4-31
Protection Parameters	4-32
Display Parameters	4-37
Communications Parameters	4-38

Chapter 5: GS1 Modbus Communications	5-1
Communications Parameters Summary (P9.xx)	5-2
GS1 Parameter Memory Addresses	5-3
GS1 Status Addresses	5-7
Block Transfer Parameters for Modbus Programs	5-9
Communicating with AutomationDirect PLCs.	5-9
Step 1: Choose the Appropriate CPU	5-9
Step 2: Make the Connections	5-9
Step 3: Set AC Drive Parameters	5-13
Step 4: Configure the PLC CPU	5-13
CLICK Modbus Ladder Programming	5-17
Separate Run Command Write Instruction.	5-17
CLICK Communication Program Example – (for CLICK PLCs)	5-18
Direct LOGIC Modbus Ladder Programming	5-32
Separate Run Command Write Instruction.	5-32
Block Transfer Parameters for Modbus Programs	5-32
DirectLOGIC Basic Communication Program – start with this code	5-33
Programming Differences for DirectLOGIC PLCs.	5-34
DL MRX/MWX Communication Program – for DL06 & D2-260 PLCs	5-35
DL RX/WX Communication Program – for DL05, D2-250(-1), D4-450 PLCs.	5-48
Communicating with Third-Party Devices.	5-61
Common Third-Party MODBUS RTU Masters	5-61
Using Modbus ASCII	5-62
Comm Delay – Optimizing Communications	5-68
Optimizing Communications to GS Drives.	5-68
Types of Messages Sent to GS Drives.	5-69
Format of “Read Registers” Messages:	5-69
Format of “Write Multiple Registers” Messages:.	5-69
Format of “Write Single Register” Messages:	5-69
Example Message:	5-69
Additional Message Delay Times	5-70
Communication Delay Summary	5-72
 Chapter 6: Maintenance and Troubleshooting.	 6-1
Maintenance and Inspection	6-2
Monthly Inspection:	6-2
Annual Inspection	6-2
Recharge Capacitors (for unused drives)	6-2
Troubleshooting	6-3
Fault Codes	6-3
Warning Messages.	6-4

<i>Appendix A: Accessories</i>	A-1
<i>Accessories Part Numbering</i>	A-2
<i>Line Reactors</i>	A-2
<i>Line Reactor Specifications – LR(2) Series</i>	A-3
<i>Line Reactor Dimensions – LR(2) Series</i>	A-4
<i>Line Reactor Applications and Connections</i>	A-10
<i>Drive Output Filter</i>	A-13
<i>Drive Output Filter Dimensions – VTF Series</i>	A-14
<i>RF Filter</i>	A-15
<i>RF Filter Dimensions</i>	A-15
<i>RF Filter Wiring</i>	A-15
<i>Fuses and Fuse Kits</i>	A-16
<i>Fuse Block Dimensions</i>	A-16
<i>Fuse Block Single-Phase 115VAC Wiring</i>	A-16
<i>Ethernet Interface</i>	A-17
<i>ZIPLink™ Cables for RS-485 Modbus RTU</i>	A-18
<i>GS Drive Configuration Software</i>	A-19
<i>Software Functions</i>	A-19
<i>System Requirements</i>	A-19
<i>Configuration Cable</i>	A-19
<i>Appendix B: Using GS1 AC Drives with AutomationDirect PLCs</i>	B-1
<i>Compatible AutomationDirect PLCs and Modules</i>	B-2
<i>Typical PLC Connections to GS1 Series AC Drives</i>	B-6
<i>CLICK CPU and DC Output Modules (Sinking)</i>	B-6
<i>CLICK CPU Modules with Non-isolated Analog Outputs</i>	B-7
<i>DirectLOGIC DC Output Modules (Sinking)</i>	B-8
<i>DirectLOGIC Isolated Analog Output Modules</i>	B-9
<i>DirectLOGIC Non-isolated Voltage or Sourcing Current Analog Output Modules</i>	B-10