



Liebert®

PSI5 120V Input/120V Output
& 208V Input/208V Output

Installer/User Guide

The information contained in this document is subject to change without notice and may not be suitable for all applications. While every precaution has been taken to ensure the accuracy and completeness of this document, Vertiv assumes no responsibility and disclaims all liability for damages resulting from use of this information or for any errors or omissions. Refer to other local practices or building codes as applicable for the correct methods, tools, and materials to be used in performing procedures not specifically described in this document.

The products covered by this instruction manual are manufactured and/or sold by Vertiv. This document is the property of Vertiv and contains confidential and proprietary information owned by Vertiv. Any copying, use or disclosure of it without the written permission of Vertiv is strictly prohibited.

Names of companies and products are trademarks or registered trademarks of the respective companies. Any questions regarding usage of trademark names should be directed to the original manufacturer.

Technical Support Site

If you encounter any installation or operational issues with your product, check the pertinent section of this manual to see if the issue can be resolved by following outlined procedures.

Visit <https://www.Vertiv.com/en-us/support/> for additional assistance.

TABLE OF CONTENTS

Important Safety Information	1
1 PS15 Description	3
1.1 Available Models	3
1.2 Rear Panel Views	4
1.3 Front Panel	12
2 Installation	15
2.1 What's Included	15
2.2 Unpacking and Inspection	15
2.3 Preparation for Installation	15
2.3.1 Installation Environment	15
2.3.2 Installation Clearances	15
2.4 Installing the UPS	16
2.4.1 Installing a 2U or LI Model	16
2.4.2 Installing a 1U Model	19
2.4.3 Installing a Mini Tower (MT) Model	19
2.5 Connecting Loads	19
2.6 Connecting for Network Protection (Optional)	19
2.7 USB Connection	20
2.8 Emergency Power Off (EPO) Connection (Optional)	20
2.9 External Battery Cabinet Connection on 2U Models (Optional)	20
2.10 Network Communication Card Connection (Optional)	21
2.10.1 Connecting AC Input	21
3 Operation	23
3.1 Modes of Operation	23
3.1.1 Off Mode	23
3.1.2 On/Normal Mode	23
3.1.3 On/Automatic Voltage Regulation (AVR)/Boost Mode	23
3.1.4 On/Automatic Voltage Regulation (AVR)/Buck Mode	23
3.1.5 On/Battery Mode	23
3.1.6 Fault Mode	23
3.1.7 Battery Self-Test Mode	23
3.1.8 Controls	24
3.2 Display Panel Indicators	26
3.3 Audible-Tone Indicators	27
3.4 Warnings	28
3.5 Faults	29
3.6 Normal Startup	29
3.7 Normal Shutdown	29
3.8 Full Shutdown	29
3.9 Configuring UPS with the Settings Menu	30

4 Maintenance and Battery Replacement	33
4.1 Precautions	33
4.2 Battery Charging	33
4.3 Replacing the UPS Batteries	33
5 Specifications	37
5.1 Run Times	46

IMPORTANT SAFETY INFORMATION

IMPORTANT! This manual contains important safety instructions that must be followed during the installation and maintenance of the UPS and batteries. Read this manual thoroughly and the safety and regulatory information, available at <https://www.vertiv.com/ComplianceRegulatoryInfo>, before attempting to install, connect to supply, or operate this UPS.

This page intentionally left blank

1 PSI5 DESCRIPTION

The Liebert®PSI5 is a line-interactive UPS designed for IT applications such as network closets and small data centers. It is available in 1U, 2U, MT (mini tower) and LI (lithium-ion) form factors. It provides reliable power protection for servers, critical nodes, network workstations, large network peripherals, network routers, bridges, hubs and other electronic equipment. Matching battery cabinets are available to extend the on-battery operating time for 2U models. The optional Liebert® Network Communication Card makes advanced monitoring and control available.

1.1 Available Models

Table 1.1 PSI5 Models

MODEL FORM FACTOR	MODEL NUMBER	NOMINAL POWER RATING (120V INPUT)
2U	PSI5-800RT120	800VA/720 W
	PSI5-1100RT120	1100VA/990W
	PSI5-1500RT120	1500VA/1350W
	PSI5-2200RT120	1920VA/1920W
	PSI5-3000RT120	3000VA/2700W
	PSI5-5000RT208	5000VA/4500W
1U	PSI5-1000RM1201U	1000VA/900W
	PSI5-1500RM1201U	1440VA/1350W
Mini Tower	PSI5-750MT120	750VA/675W
	PSI5-1100MT120	1100VA/990W
	PSI5-1500MT120	1440VA/1350W
Lithium-Ion	PSI5-1500RT120LI	1440VA/1350W
	PSI5-3000RT120LI	2880 VA/2700W

1.2 Rear Panel Views

Figure 1.1 Liebert® PSI5-800/1100/1500RT120 Rear Panel




Table 1.2 PSI5-800/1100/1500RT120 Rear Panel Descriptions

ITEM	DESCRIPTION
1	Grounding Screw
2	Network/Fax/Modem Surge Protection Input/Output
3	External Battery Connector
4	USB Port
5	Programmable Receptacles
6	Non-Programmable Receptacles
7	SNMP IntelliSlot Port
8	Emergency Power Off (EPO) Connector
9	Input Circuit Breaker
10	AC Input

Figure 1.2 Liebert® PSI5-2200RT120 Rear Panel




Table 1.3 PSI5-2200RT120 Rear Panel Descriptions

ITEM	DESCRIPTION
1	Grounding Screw
2	Network/Fax/Modem Surge Protection Input/Output
3	External Battery Connector
4	USB Port
5	Programmable Receptacles
6	Non-Programmable Receptacles
7	SNMP IntelliSlot Port
8	Emergency Power Off (EPO) Connector
9	Input Circuit Breaker
10	AC Input

Figure 1.3 Liebert® PSI5-3000RT120 Rear Panel




Table 1.4 PSI5-3000RT120 Rear Panel Descriptions

ITEM	DESCRIPTION
1	Grounding Screw
2	Network/Fax/Modem Surge Protection Input/Output
3	External Battery Connector
4	USB Port
5	Programmable Receptacles
6	Non-Programmable Receptacles
7	SNMP IntelliSlot Port
8	Emergency Power Off (EPO) Connector
9	Input Circuit Breaker
10	AC Input
11	Output Circuit Breaker

Figure 1.4 Liebert® PSI5-5000RT208 Rear Panel




Table 1.5 PSI5-5000RT208 Rear Panel Descriptions

ITEM	DESCRIPTION
1	Grounding Screw
2	Network/Fax/Modem Surge Protection Input/Output
3	External Battery Connector
4	USB Port
5	Programmable Receptacles
6	Non-Programmable Receptacles
7	SNMP IntelliSlot Port
8	Emergency Power Off (EPO) Connector
9	Input Circuit Breaker
10	AC Input

Figure 1.5 PS15-1000/1500RM1201U Rear Panel




Table 1.6 Liebert® PS15-1000/1500RM1201U Rear Panel Descriptions

ITEM	DESCRIPTION
1	Liebert® IntelliSlot Port
2	Input Circuit Breaker
3	AC Input
4	Emergency Power Off (EPO) Connector
5	USB Port
6	Programmable Receptacles
7	Non-Programmable Receptacles

Figure 1.6 Liebert® PSI5 Mini Tower Rear Panels





Table 1.7 Mini Tower Rear Panel Descriptions


ITEM	DESCRIPTION
1	PSI5-750/1100MT120
2	PSI5-1500MT120
3	Network/Phone/DSL Surge-Protection Connectors
4	Grounding Screw
5	Liebert® IntelliSlot Port
6	Non-Programmable Receptacles
7	Programmable Receptacles
8	AC Input
9	USB Port
10	AC Input Breaker
11	Emergency Power Off (EPO) Connector

Figure 1.7 Liebert PSI5-1500RT120LI Rear Panel



ITEM	DESCRIPTION
1	AC Input
2	Network/Fax/Modem Surge Protection Input/Output
3	External Battery Connector
4	USB Port
5	SNMP IntelliSlot™ Port
6	Programmable Receptacles
7	Non-Programmable Receptacles
8	Emergency Power Off (EPO) Connector
9	Input Circuit Breaker
10	Grounding Screw

Figure 1.8 Liebert PSI5-3000RT120LI Rear Panel




ITEM	DESCRIPTION
1	AC Input
2	External Battery Connector
3	Network/Fax/Modem Surge Protection Input/Output
4	SNMP IntelliSlot™ Port
5	USB Port
6	Programmable Receptacles
7	Non-Programmable Receptacles
8	Output Circuit Breakers
9	Emergency Power Off (EPO) Connector
10	Input Circuit Breaker
	Grounding Screw

1.3 Front Panel


NOTE: For detailed descriptions of the LCD, see [Display Panel Indicators](#) on page 26.

Figure 1.9 Controls and Display on 2U, MT and LI Models



ITEM	DESCRIPTION
1	ON/MUTE button. See Controls on page 24, for details.
2	SELECT button. See Controls on page 24, for details.
3	OFF/ENTER button. See Controls on page 24, for details.

Figure 1.10 Controls and Display on 1U Models



ITEM	DESCRIPTION
1	ON/MUTE button. See Controls on page 24, for details.
2	SELECT button. See Controls on page 24, for details.
3	OFF/ENTER button. See Controls on page 24, for details.

This page intentionally left blank

2 INSTALLATION

2.1 What's Included

- USB cable; one 2 m (6.5 ft) long
- Quick installation guide
- Safety and regulatory guidelines
- Tower support stands (2U and LI models only)
- Rack-mount rail kit (1U, 2U, and LI models only)

2.2 Unpacking and Inspection

Unpack the UPS and conduct the following checks:

- Inspect the UPS for shipping damage. If any shipping damage is found, report it to the carrier and your local dealer or your Vertiv™ representative immediately.
- Check the accessories included in the packing list. If there is any discrepancy, contact your local dealer or your Vertiv representative immediately.

2.3 Preparation for Installation

2.3.1 Installation Environment

- Install the UPS indoors in a controlled environment where it cannot be accidentally turned Off. The installation environment should meet the conditions listed in [Specifications](#) on page 37.
- Place it in an area of unrestricted airflow around the unit, away from water, flammable liquids, gases, corrosives and conductive contaminants. Avoid direct sunlight.
- The socket outlet should be nearby and easily accessible.
- This UPS is not for use in a computer room as defined in the standard for the Protection of Electronic Computer/Data Processing Equipment ANSI/NFPA 75.

NOTE: Operating the UPS in temperatures above 77°F (25°C) reduces battery life.

2.3.2 Installation Clearances

Maintain at least 4 in. (100mm) clearance in the front and rear. Do not obstruct the air inlets on the front panel and rear panel. Blocking the air inlets reduces ventilation and heat dissipation, shortening the service life of the UPS.

2.4 Installing the UPS


2.4.1 Installing a 2U or LI Model

The 2U UPS and optional battery cabinets may be installed in a tower or rack configuration. The LI models may also be installed in a tower or rack configuration but do **not** support external battery cabinets. Determine the configuration that meets your application needs, see [Tower Installation](#) below, or [Rack-Mount Installation](#) on the facing page.

Tower Installation


When using the UPS in a tower configuration, see [Figure 2.1](#) below. If you have an external battery, see [Figure 2.2](#) on the facing page.

Figure 2.1 Attaching stands to the UPS



ITEM	DESCRIPTION
1	Rotate the display by pulling out, and turning it clockwise until it is seated in the proper orientation.
2	Connect the two halves of the stand together.
3	Place the UPS in the stands.
4	Make sure that the stands are installed 70 mm (2.76 in.) from the edge of the unit.

Figure 2.2 Attaching stands to the UPS and external battery



ITEM	DESCRIPTION
1	Connect the two halves of the stand to the spacer, after installing the additional stand components shown in item 4, and install the securing screws.
2	Place the UPS and external battery pack in the stands. (Rotate the display on the UPS if needed, see Figure 2.1 on the previous page.)
3	Make sure that the stands are installed 70 mm (2.76 in.) from the edge of the unit.
4	Insert the stand expansion components and install the securing screws.


Rack-Mount Installation



CAUTION: Do not use the mounting brackets to lift the unit. Use the mounting brackets only to secure the UPS to the rack.


When using the UPS in a rack, see **Figure 2.3** on the next page to install the unit. If you have an external battery, see **Figure 2.4** on the next page.

Figure 2.3 Installing the UPS in a rack



ITEM	DESCRIPTION
1	Attach the brackets to the UPS.
2	Install the supplied rack kit into the rack.
3	Install the UPS in the rack.

Figure 2.4 Installing the external battery in a rack



ITEM	DESCRIPTION
1	Attach the brackets to the external battery.
2	Install the supplied rack kit into the rack.
3	Install the external battery in the rack.


2.4.2 Installing a 1U Model



CAUTION: Do not use the mounting brackets to lift the unit. Use the mounting brackets only to secure the UPS to the rack.

See **Figure 2.5** below to install the unit.

Figure 2.5 Installing the UPS in a rack



ITEM	DESCRIPTION
1	Attach the brackets to the UPS.
2	Install the supplied rack kit into the rack.
3	Install the UPS in the rack.

2.4.3 Installing a Mini Tower (MT) Model

Place the unit upright, on its feet without blocking air inlets.

2.5 Connecting Loads

The UPS has non-programmable and programmable outlets. Plug your critical equipment (such as computer, monitors, etc.) into the non-programmable outlets and your less-critical equipment (such as printers and other less-often used peripherals) into the programmable outlets.

2.6 Connecting for Network Protection (Optional)

Protection from electrical surges to your computer network or telephone is provided on 2U and MT models. Use the network/fax/modem surge-protection ports on the rear panel. Connect the “IN” port to the line from the wall jack and the “OUT” port to your device port. Use of this feature is not required for proper operation of the UPS.

2.7 USB Connection

You can connect the Liebert® PSI5 to a computer via USB allowing unattended, controlled shutdown of your computer in case of UPS input power failure. The UPS works with the computer running software contained in the Microsoft® Windows® operating system. Use of this feature is not required for proper operation of the UPS. To use this feature, plug the provided USB cable into USB Type-B port located on the rear panel of the UPS and the other end into an open USB port on your computer.

2.8 Emergency Power Off (EPO) Connection (Optional)

To comply with national and local wiring codes and regulations, the EPO connector internally disconnects all power sources to the UPS and connected equipment. The default operation is "active open" which means you must remove the factory-installed jumper and connect to external contacts that are normally closed but which open during a power-off event. The logic may be reversed in the Settings; see [Configuring UPS with the Settings Menu](#) on page 30. If you do not use the EPO connector, leave the factory-installed jumper in place and the default EPO settings in the Settings.

2.9 External Battery Cabinet Connection on 2U Models (Optional)

External battery cabinets provide longer battery run time for connected devices. Refer to [Specifications](#) on page 37, and [Run Times](#) on page 46, to select the appropriate model and quantity for your PSI5 model and applications. You can connect up to six battery cabinets to the 2U PSI5 models. 1U, MT, and 1U models do not support external battery cabinets.


To connect an external battery pack:

1. Connect one end of the external battery cable to the UPS and one end to the battery cabinet as shown in **Figure 2.6** on the facing page.
2. If connecting more than one external battery, connect one end of the external battery cable to the second connector on the battery cabinet, then connect the other end to the next battery cabinet as shown in **Figure 2.6** on the facing page.

NOTE: After installation and initial startup, set the number of installed battery cabinets in the UPS Settings.

NOTE: When two or more external battery cabinets are used with PSI5-1100/2200/3000/5000 models, the UPS load rating is decreased by 20%.

Figure 2.6 Connecting External Batteries



ITEM	DESCRIPTION
1	Connection to second connector on external battery cabinet for additional battery cabinets.
2	Connection from UPS to single/first external battery.
3	Connect to next external battery.
4	Connection to UPS.

2.10 Network Communication Card Connection (Optional)

For external status monitoring, there is a Network Communication Port where one of the network cards may be installed:

- Liebert®IntelliSlot Relay card, IS-UNITY-SNMP
- Liebert®IntelliSlot Unity card, IS-UNITY-DP

To install the card:

1. Remove the two screws and protective cover on the Network Communications Port on the rear panel.
2. Insert the card into the port and secure it with the screws.
3. Refer to the documentation with the card or at www.Vertiv.com for cable connection and operation.

2.10.1 Connecting AC Input



CAUTION: For 1U and MT UPS models, to reduce the risk of fire, connect only to a circuit provided with 20A maximum branch circuit overcurrent protection in accordance with the National Electrical Code, ANSI/NFPA 70 and the Canadian Electrical Code, Part I, C22.1.

Ensure that all the loads are first powered Off. Connect to an input power supply/wall outlet that is properly protected by a circuit breaker in accordance with national and local electrical codes. The input receptacle must be grounded. See [Specifications](#) on page 37, for input cord rating.

Once the UPS is plugged into the wall outlet, it begins charging the battery.

NOTE: While every precaution has been taken to ensure that the battery is in good condition, Vertiv™ recommends plugging the UPS into AC input and to charge the battery for at least 12 hours prior to providing full backup time protection for any utility power abnormality.

3 OPERATION

3.1 Modes of Operation

3.1.1 Off Mode

The UPS input is plugged into a stable, nominal source, but the outlets are turned Off. The internal batteries are charging.

3.1.2 On/Normal Mode

The UPS input is plugged into a stable, nominal source, and the outlets are turned On. The internal batteries are charging.

3.1.3 On/Automatic Voltage Regulation (AVR)/Boost Mode

The UPS input is plugged in, but the voltage source is abnormally low (brown-out). The UPS automatically corrects the low voltage and allows the outlets to be On with the normal, expected voltage. The internal batteries are charging.

3.1.4 On/Automatic Voltage Regulation (AVR)/Buck Mode

The UPS input is plugged in, but the voltage source is abnormally high. The UPS automatically corrects the high voltage and allows the outlets to be On with the normal, expected voltage. The internal batteries are charging.

3.1.5 On/Battery Mode

The UPS input is not plugged in or the voltage source has become extremely low or high and unusable. The UPS automatically switches to the internal battery to provide normal, usable voltage to the outlets.

3.1.6 Fault Mode

An error or fault condition has occurred. The outlets are shut Off.

3.1.7 Battery Self-Test Mode

The UPS enters a cycle of approximately 10 seconds during which it tests the internal battery. The outlets are still temporarily powered by the internal battery. Self-test mode occurs at the following instances:

- At startup turning the UPS On.
- Automatically every 8 weeks as a self-check.
- Manually by pressing and holding the ON/Mute button for 3 seconds when the unit is On.

3.1.8 Controls

Figure 3.1 Display and Buttons on the front panel of 2U and MT units




Figure 3.2 Display and Buttons on the front panel of 1U units




Table 3.1 Control button descriptions

ITEM	DESCRIPTION
1	<p>On/Mute Button. Powers the UPS On and other functions depending on the current operating mode.</p> <ul style="list-style-type: none"> • UPS On: When in Off mode, press and hold for 2 seconds to enter Battery Self-Test mode, then On mode. • Manual Battery Self-Check: Press and hold for 3 seconds to temporarily enter Battery Self-Test mode. • Mute: When in On/Battery mode, press and hold for 3 seconds. • Settings Menu UP: When in the Settings Menu, press to cycle Up through options; see Configuring UPS with the Settings Menu on page 30.
2	<p>Select Button.</p> <ul style="list-style-type: none"> • Select: Press to cycle through the operating parameters. • Settings Menu: When in Off mode, press and hold for 3 seconds. • Settings menu DOWN: When in Settings Menu, press to cycle down through setting options, see Configuring UPS with the Settings Menu on page 30.
3	<p>OFF/Enter Button.</p> <ul style="list-style-type: none"> • UPS Off: When in On mode, press and hold for 2 seconds to enter Off mode. • Settings menu ENTER: When in the Settings Menu, press to confirm selections, see Configuring UPS with the Settings Menu on page 30.

NOTE: Press any button quickly to wake the display.

3.2 Display Panel Indicators

NOTE: The display automatically powers Off to conserve power.

Figure 3.1 on page 24, shows the LCD on the front panel of the UPS.

Table 3.2 Display icons, sections and functions


















ICONS AND DISPLAY	DESCRIPTION
	Off mode
	On/Normal mode
	On/AVR/Boost mode
	On/AVR/Buck mode
	On/Battery mode
	Estimated backup time in H (hours), M (minutes), or S (seconds)
	Indicates warning and fault codes. See Faults on page 29, and Warnings on page 28.
	Displays various UPS operation parameters.
	Settings menu. See Configuring UPS with the Settings Menu on page 30.
	Audible On/Battery mode alarm silenced

Table 3.2 Display icons, sections and functions (continued)

ICONS AND DISPLAY	DESCRIPTION
	UPS output load in 25% increments
	Battery level in 25% increments
	Low battery
	Overload icon
	Programmable outlet icon
	Battery icon
	Battery charging icon

3.3 Audible-Tone Indicators

Table 3.3 Tones and Beeps of the UPS

TYPE	INDICATES
1 beep every 10 seconds	Battery mode
1 beep every second	Overload warning
1 beep every 2 seconds	Low-battery warning
	Other warning
Constant, solid tone	Fault
1 beep	Power On
	Battery self-test
	Button press
1 long tone	Power Off

3.4 Warnings

The UPS has early warning indicators that allow the UPS to function normally for a short period before the outputs are shut Off.

Table 3.4 Warning Indicators and Actions

DISPLAY	DESCRIPTION	TROUBLESHOOTING
bl	Battery low	Charge the UPS battery for at least 12 hours or replace the battery; see Replacing the UPS Batteries on page 33.
OL	Overload	Reduce the load to below the rating indicated in the Specifications on page 37.
SF	Site wiring fault	Turn Off the UPS and call an electrician to correct the wiring. Possible causes are that the line and neutral are reversed or that there is no ground conductor.
EP	Over temperature	Call Vertiv™ customer support, 1-800-222-5877.
CH	Charger failure	Call Vertiv customer support, 1-800-222-5877.
bf	Battery fault	Charge the UPS battery for at least 12 hours or replace the battery; see Replacing the UPS Batteries on page 33.
BR	Battery replacement	Charge the UPS battery for at least 12 hours or replace the battery; see Replacing the UPS Batteries on page 33.
EE	EEPROM error	Call Vertiv customer support, 1-800-222-5877.
nc	Internal battery is not connected	Check the connection of the battery, see Replacing the UPS Batteries on page 33.
OC	Over charge	Call Vertiv customer support, 1-800-222-5877.
EP	Emergency Power Off activated	Remove the EPO state on the EPO connector. NOTE: Output immediately shuts Off when the EPO warning occurs.

3.5 Faults

The UPS displays fault codes when it detects a problem and automatically shuts Off output power.

Table 3.5 Fault Codes and Actions

CODE	DESCRIPTION	TROUBLESHOOTING
01	Bus start fail	Call Vertiv™ customer support, 1-800-222-5877.
02	Bus over	
03	Bus under	
11	Inverter soft start fail	
12	Inverter voltage high	Turn Off the UPS, disconnect all connected loads and restart the UPS. If the fault is still active, call Vertiv customer support, 1-800-222-5877. If the fault is no longer active, plug each piece of equipment in one at a time to locate the device that has the short circuit.
13	Inverter voltage low	
14	Inverter output short	
27	Battery voltage too high	Replace the battery or call Vertiv customer support, 1-800-222-5877.
28	Battery voltage too low	
41	Over temperature	Make sure that the air temperature is within the range listed in Specifications on page 37. Otherwise, call Vertiv customer support, 1-800-222-5877.
43	Overload	Reduce the load to below the UPS rating listed in Specifications on page 37, and restart the UPS.
45	Charger failure	Call Vertiv customer support, 1-800-222-5877.

3.6 Normal Startup

- With the UPS connected to AC input, press and hold the ON/MUTE button for 2 seconds. The UPS is in Battery Self-Test mode for 10 seconds. After a successful self-test, the UPS is On.

3.7 Normal Shutdown

1. Press and hold the power button for 2 seconds. The outlets are turned Off.
2. Disconnect AC input power.


3.8 Full Shutdown

1. Press and hold the power button for 2 seconds. The outlets are turned Off.
2. Remove the front bezel, disconnect the battery connector and replace the front bezel. The unit is fully shut down.

3.9 Configuring UPS with the Settings Menu

You may adjust several settings to configure the UPS to operate with your equipment. In Settings mode, the UPS displays two parameter fields (see **Figure 3.3** below. The first selects the program option to configure, and the second lists the parameter values for selection for each program option. **Table 3.6** on the facing page describes the program options. In addition, symbols relevant to the program option may be shown. The symbols are described in **Table 3.2** on page 26.

Figure 3.3 UPS Display in Settings Mode



ITEM	DESCRIPTION
1	Program option
2	Settings options for selection

To access Settings mode and adjust settings:

1. Power-Off the UPS by pressing the OFF/Enter button for at least 2 seconds.
2. Press and hold the Select button for 3 seconds.
Settings mode displays; see **Figure 3.3** above.
3. Use the up/down arrow buttons to display the number of the program function to adjust, then press OFF/Enter. See **Table 3.6** on the facing page, for the options.
4. Use the up/down arrow buttons to select the setting, then press OFF/Enter. See **Table 3.6** on the facing page, for the settings.
5. When finished, select program option 00, and press OFF/Enter to exit Settings mode.

Table 3.6 Settings Menu Options

PROGRAM NUMBER	SETTING OPTIONS
01	<p>Nominal voltage setting. Set the nominal system voltage to match the input voltage of the UPS. This setting affects the buck/boost/on-battery transfer points and sets the output voltage in Battery mode.</p> <p>For 120VAC models:</p> <ul style="list-style-type: none"> • 100 = 100VAC • 110 = 110VAC • 115 = 115VAC • 120 = 120VAC (default) • 125 = 125VAC <p>For 208-VAC models</p> <ul style="list-style-type: none"> • 200 = 200VAC • 208 = 208VAC (default) • 240 = 240VAC
02	<p>Enable/Disable programmable outlets.</p> <ul style="list-style-type: none"> • ENA = Enable • DIS = Disable (default)
03	<p>Programmable outlets time limit. Set a maximum time the programmable outlets are powered when running on battery. Setting a shorter time limit for programmable outlets extends the time the non-programmable outlets are powered when running on battery.</p> <ul style="list-style-type: none"> • 0 to 999 = minutes (999 is default)
04	<p>Enable/Disable site fault detection.</p> <ul style="list-style-type: none"> • ENA = Enable (default) • DIS = Disable
05	<p>Enable/Disable neutral grounding in battery mode.</p> <ul style="list-style-type: none"> • ENA = Enable (default) • DIS = Disable
06	<p>Non-programmable outlets time limit. Set a maximum time the non-programmable outlets are powered when running on battery.</p> <ul style="list-style-type: none"> • 0 to 999 = minutes, selecting 0 (zero) sets a limit of 10 seconds. • DIS = Disable. Backup time depends on battery capacity (default)
07	<p>Set the number of connected external battery cabinets. (Available only on 2U models)</p> <ul style="list-style-type: none"> • 0 to 6 (0 is default) <p>NOTE: For the Liebert® PS15-1100/2200/3000/5000: When using two or more external battery cabinets (EBCs) the UPS load rating will be decreased by 20%. The % load graph on the LCD automatically adjusts to reflect this derating.</p>
08	<p>Set the Emergency Power Off (EPO) logic function.</p> <ul style="list-style-type: none"> • AO = Active Open (default) Activates Emergency Power Off when EPO connector pins are not jumpered (open). • AC = Active Close Activates Emergency Power Off when EPO connector pins are jumpered (closed).
09	<p>Set the sensitivity of acceptable input voltage quality. When distortion or disturbances are detected on the input voltage, the UPS protects the plugged-in equipment by switching to Battery mode. The lower the sensitivity setting, the less frequently the UPS switches to battery, but the more distortion and noise may be passed through to the plugged-in equipment. If you are using a poor quality input source such as a generator or step-wave source on which your equipment can fully operate, a lower sensitivity setting may provide longer battery life and run times.</p> <ul style="list-style-type: none"> • ST1 - High sensitivity (default). Provides the maximum protection. The transfer time is typically 4 to 6 ms, 10 ms max. • ST2 - Medium sensitivity. Provides medium protection. The transfer is typically 6 to 8 ms, 11 ms max. • ST3 - Low sensitivity. Provides the least protection but may provide longer battery life and run time for tolerant equipment. The transfer time is typically 8 to 10 ms, 13 ms max.
00	<p>Exit Settings mode.</p>

This page intentionally left blank

4 MAINTENANCE AND BATTERY REPLACEMENT

4.1 Precautions

Although the Liebert® PSI5 is designed and manufactured to ensure personal safety, improper use can result in electrical shock or fire. To ensure safety, observe the following precautions:

- Turn Off and unplug the UPS before cleaning it.
- Clean the UPS with a dry cloth. Do not use liquid or aerosol cleaners.
- Never block or insert any objects into the ventilation holes or other openings of the UPS.
- Do not place the UPS power cord where it might be damaged.

4.2 Battery Charging

The batteries are valve-regulated, non-spillable, lead-acid in all models except for the LI, which uses LiFePO₄ type lithium-ion batteries. In all cases, the batteries should be kept charged to retain their design life. The PSI5 charges the batteries continuously when it is connected to input power. If the PSI5 will be stored for a long time, Vertiv™ recommends connecting the UPS to input power every 4 to 6 months for at least 2 hours for LI models and 24 hours for lead acid models to ensure full recharge of the batteries.

4.3 Replacing the UPS Batteries

IMPORTANT! Before you proceed, please review the battery safety precautions available at <https://www.vertivco.com/ComplianceRegulatoryInfo>.

You may safely replace the internal battery pack. See the [Specifications](#) on page 37, for the part number of the replacement battery for your UPS model number.

NOTE: Replace the battery with the same type and number as originally installed.


NOTE: The internal battery pack is hot-swappable. However, caution should be exercised because during this procedure the load is unprotected from disturbances and power outages. Do not replace the battery while the UPS is operating in Battery Mode. This will result in a loss of output power and will drop the connected load.

To replace the batteries on 1U and 2U models:

1. Remove the front bezel by pulling firmly until the snaps release.
2. Disconnect the battery connector by squeezing the ends and gently pulling the two pieces apart.
3. Remove the two screws and the metal battery cover plate.
4. Slide out the existing battery kit and disconnect the battery terminals from the connector. Disconnect the red wire first, then the black.
5. Plug the removed connector into the terminals of the new replacement battery kit. Plug the black wire in first, then the red.
6. Orient the connector and the new battery in the same way as the original battery and slide into UPS.
7. Reconnect the two halves of the battery connector and slide the front panel back on until it clicks.
8. Replace the metal plate and secure with the two screws.
9. Snap the front bezel back on.


10. Press and hold the power button for 3 seconds to initiate the Battery-Self Check mode clearing any previous battery fault warning.
11. Properly dispose of the old batteries at an appropriate recycling facility or return them to Vertiv™ in the packing material from the new batteries.

Figure 4.1 Removing the battery box from 2U units to replace batteries



ITEM	DESCRIPTION
1	Remove the front panel from the UPS.
2	Disconnect the battery wires.
3	Remove the 2 screws on the front panel of the battery box, and pull out the box.
4	Remove the top cover, place the batteries inside, and return the cover to the battery box.
5	Place the battery box in the UPS, and re-install the front panel of the battery box.
6	Connect the battery wires.
7	Replace the front panel on the UPS.

Figure 4.2 Removing the battery box from 1U units to replace batteries




ITEM	DESCRIPTION
1	Remove front panel.
2	Disconnect red then black wire from battery terminals.
3	Remove screws and metal battery cover.
4	Connect black then red wire to battery terminals.
5	Slide the replacement battery kit into the UPS. Replace the metal plate and secure with the two screws.
6	Reconnect the battery connector.
7	Snap the front panel back on.

To replace the batteries on MT models:

1. Place the unit on its left side and remove the 6 screws and the metal battery cover plate.
2. Slide out the existing battery kit and disconnect the two halves of the battery connector.
3. Orient the connector and the new battery in the same way as the original battery, connect the two halves of the battery connector, and slide into UPS.
4. Replace the metal plate and secure with the 6 screws.
5. Press and hold the power button for 3 seconds to initiate the Battery-Self Check mode clearing any previous battery fault warning.
6. Properly dispose of the old batteries at an appropriate recycling facility or return them to Vertiv™ in the packing material from the new batteries.

Figure 4.3 Replacing the batteries on MT models



ITEM	DESCRIPTION
1	With unit laying on left side, remove screws from battery cover.
2	Remove the battery cover.
3	Slide out the battery kit and disconnect the battery connector.
4	Connect the battery connector to the replacement battery.
5	Slide the replacement battery kit into the UPS.
6	Replace the battery cover.
7	Secure the battery cover with the screws.

5 SPECIFICATIONS

Table 5.1 on the next page, lists the specification for the Liebert® PSI5 2U UPS models.

Table 5.2 on page 41, lists the specification for the PSI5 1U and MT UPS models.

Table 5.1 PS15 Specifications for 2U Models

MODEL	PS15-800RT120 / PS15-800RT120TAA	PS15-1100RT120 / PS15-1100RT120TAA	PS15-1500RT120 / PS15-1500RT120TAA	PS15-2200RT120 / PS15-2200RT120TAA	PS15-3000RT120 / PS15-3000RT120TAA	PS15-5000RT208 / PS15-5000RT208TAA
Power Rating						
125VAC input	800VA, 720W, 6.4A	1100 VA, 990W, 8.8A	1500 VA, 1350W, 12A	1920 VA, 1920W, 15.4A	3000 VA, 270W, 24A	–
120VAC input	800 VA, 720W, 6.7A	1100 VA, 990W, 9.2A	1500 VA, 1350W, 12A	1920 VA, 1920W, 16A	2880 VA, 2700W, 24A	–
115VAC input	800 VA, 720W, 7.0A	1100 VA, 99.0W, 9.6A	1500 VA, 1350W, 12A	1840 VA, 1840W, 16A	2760 VA, 2700W, 24A	–
110VAC input	680 VA, 612W, 6.2A	935 VA, 842W, 8.5A	1275 VA, 1147W, 11.6A	1632 VA, 1632W, 14.8A	2550 VA, 2295W, 23.2A	–
100VAC input	680 VA, 612W, 6.8A	935 VA, 842W, 9.4A	1200 VA, 1147W, 12A	1600 VA, 1600W, 16A	2400 VA, 2400W, 24A	–
240VAC input	–	–	–	–	–	5000 VA, 4500W, 20.8A
230VAC input	–	–	–	–	–	5000 VA, 4500W, 21.7A
220VAC input	–	–	–	–	–	5000 VA, 4500W, 22.7A
208VAC input	–	–	–	–	–	4250 VA, 3825W, 20.4A
200VAC input	–	–	–	–	–	4250 VA, 3825W, 21.3A
Dimensions and Weights						
Unit Dimensions, W x D x H, in. (mm)	17.2 x 16.1 x 3.5 (438 x 410 x 88)	17.2 x 20 x 3.5 (438 x 510 x 88)	17.2 x 20 x 3.5 (438 x 510 x 88)	17.2 x 24.8 x 3.5 (438 x 630 x 88)		
Shipping Dimensions, W x D x H, in. (mm)	10.2 x 22.9 x 21.7 (258 x 582 x 550)	10.2 x 26.5 x 21.7 (258 x 672 x 550)	10.2 x 26.5 x 21.7 (258 x 672 x 550)	10.2 x 26.7 x 21.7 (258 x 782 x 550)		
Unit Weight, lb. (kg)	28.4 (12.9)	29.5 (13.4)	42.6 (19.3)	59.1 (26.8)	70.8 (32.1)	87.7 (39.8)
Shipping Weight, lb (kg)	32.2 (16.9)	37.9 (17.2)	51.8 (23.5)	70.1 (31.8)	81.8 (37.1)	98.8 (44.8)
Input						
Voltage Input Range (with battery operation)	0~150VAC					
Voltage Input Range (without battery operation)	75~146VAC					
Input Voltage Measurement Tolerance	±5%					
Nominal Voltage Setting	100 / 110 / 115 / 120 / 125VAC					
High Line Buck to Battery	117 / 129 / 135 / 140 / 146VAC					
High Line Battery to Buck	114 / 125 / 131 / 137 / 143VAC					
High Line Normal to Buck	110 / 121 / 127 / 132 / 138VAC					

Table 5.1 PSi5 Specifications for 2U Models (continued)

MODEL	PSi5-800RT120 / PSi5-800RT120TAA	PSi5-1100RT120 / PSi5-1100RT120TAA	PSi5-1500RT120 / PSi5-1500RT120TAA	PSi5-2200RT120 / PSi5-2200RT120TAA	PSi5-3000RT120 / PSi5-3000RT120TAA	PSi5-5000RT208 / PSi5-5000RT208TAA
High Line Buck to Normal	107 / 118 / 123 / 128 / 134VAC					
Low Line Boost to Normal	93 / 102 / 107 / 112 / 116VAC					
Low Line Normal to Boost	90 / 99 / 104 / 108 / 113VAC					
Low Line Battery to Boost	80 / 88 / 92 / 96 / 100VAC					
Low Line Boost to Battery	75 / 83 / 86 / 90 / 94VAC					
Frequency Input Range	55~65 Hz (57~63 Hz Battery to Normal comeback)					
Internal Rear Panel Input Breaker Rating	10A	13A	16A	20A	30A	
Input Surge Protection	ANSI C62.41 Category A, Level 3 1372J					
Input Power Cord	NEMA 5-15P, offset 90-degree type (3 m attached)		NEMA L5-20P (3 m attached) NEMA L5-20 to 5-20P adapter cord (150 mm)		NEMA L6-30P (3 m attached)	
Output						
Output Voltages (on battery)	100 / 110 / 115 / 120 / 125VAC (± 1.5 on battery before alarm) user selectable (120VAC is factory default)					
Output Frequency (on battery)	60 Hz $\pm 1\%$					
Output Receptacles - not controllable	(3) NEMA 5-15R		(3) NEMA 5-15/20R, (1) NEMA L5-20R		(3) NEMA L6-30R, (1) NEMA L5-30R	
Output Receptacles - controllable	(3) NEMA 5-15R (3) NEMA 5-20R					
Transfer Time	Adjustable with User Setting 09: ST1: 4-6ms/10ms typical (default). ST2: 6-8ms/11ms typical. ST3: 8-10ms, 13ms typical					
Output Waveform (on battery)	Pure Sinewave					
Output Overload Operation	100% - alarm warning 110% - alarm warning and shutdown after 10 seconds 120% - alarm warning and immediate shutdown					
Protection	Electronic (overcurrent, short circuit w/ latching shutdown)					
AC Mode Efficiency	96% for 100/110/115/120/125VAC					
Buck and Boost Mode Efficiency	93% for 100/110/115/120/125VAC					
Recharge Time	4 hours to recover to 90%					

Table 5.1 PS15 Specifications for 2U Models (continued)

MODEL	PS15-800RT120 / PS15-800RT120TAA	PS15-1100RT120 / PS15-1100RT120TAA	PS15-1500RT120 / PS15-1500RT120TAA	PS15-2200RT120 / PS15-2200RT120TAA	PS15-3000RT120 / PS15-3000RT120TAA	PS15-5000RT208 / PS15-5000RT208TAA
Internal Battery						
Part Number	PS15-800BATKIT	PS15-1100BATKIT	PS15-1500BATKIT	PS15-2200BATKIT	PS15-3000BATKIT	PS15-5000BATKIT
Protection	Electronic (overcurrent, short circuit with latching shutdown)					
Type	Valve-regulated lead-acid (VRLA) in compliance with UL 1989					
Battery Manufacturer/Model	Leoch/DJW12-7.0 CSB/GP1272	Leoch/DJW12-9.0 CSB/HR1234W	Leoch/DJW12-9.0 CSB/GP1272	Leoch/DJW12-9.0 CSB/HR1234W	Leoch/DJW12-9.0 CSB/HR1234W	Leoch/DJW12-10 CSB/UPS12580
Quantity x Voltage x Ah	2 x 12V x 7.0Ah	2 x 12V x 9.0Ah	4 x 12V x 7.0Ah	6 x 12V x 7.0Ah	6 x 12V x 9.0Ah	6 x 12V x 10Ah
External Battery Cabinets						
Model Number	PS15-24VBATT		PS15-48VBATT		PS15-72VBATT	
Protection	Circuit Breaker					
Type	Valve-regulated, lead-acid (VRLA) in compliance with UL 1989					
Battery Manufacturer/Model	Leoch/DJW12-9.0 CSB/HR1234W					
Quantity x Voltage x Ah	2 x 12V x 9.0Ah / 2 x 12V x 9.0Ah		4 x 12V x 9.0Ah / 4 x 12V x 9.0Ah		6 x 12V x 9.0Ah / 6 x 12V x 9.0Ah	
Dimensions, W x D x H, in. (mm)	17.2 x 16.1 x 3.5 (438 x 410 x 88)		17.2 x 20 x 3.5 (438 x 510 x 88)		17.2 x 24.8 x 3.5 (438 x 630 x 88)	
Shipping Dimensions, W x D x H, in. (mm)	10.2 x 22.9 x 21.7 (258 x 582 x 550)		10.2 x 26.5 x 21.7 (258 x 672 x 550)		10.2 x 26.7 x 21.7 (258 x 782 x 550)	
Unit Weight, lb. (kg)	37.7 (17.1)		63.9 (29.0)		90.8 (41.2)	
Shipping Weight, lb. (kg)	51.8 (23.5)		70.3 (31.9)		96.1 (43.6)	
Environmental Requirements						
Operating Temperature, °F (°C)	32 - 104 (0 - 40)					
Operating Elevation, ft. (m)	0 - 9,942 (0 - 3,000) without derating Operating temperature reduced 9° F (5° C) for each additional 1,640 ft. (500 m) of altitude.					
Relative Humidity	20% to 90% non-condensing					
Storage Temperature	-5° F to 122° F (-15° C to 50° C)					
Storage Relative Humidity	20% to 90% non-condensing					
Audible Noise	< 45 dB		< 45 dB @ Line mode < 55 dB @ Battery mode			

Table 5.2 PS15 Specifications for 1U and MT Models

	PS15-1000RM1201U	PS15-1500RM1201U	PS15-750MT120	PS15-1100MT120	PS15-1500MT120
Power Rating					
125VAC input	1000VA, 900W, 8A	1500VA, 1350W, 12A	750VA, 675W, 6A	1100VA, 990W, 8.8A	1500VA, 1350W, 12A
120VAC input	1000VA, 900W, 8.3A	1440VA, 1350W, 12A	750VA, 675W, 6.3A	1100VA, 990W, 9.2A	1440VA, 1350W, 12A
115VAC input	1000VA, 900W, 8.7A	1380VA, 1350W, 12A	750VA, 675W, 6.5A	1100VA, 990W, 9.6A	1380VA, 1350W, 12A
110VAC input	850VA, 765W, 7.7A	1275VA, 1147W, 11.6A	750VA, 675W, 6.8A	935VA, 842W, 8.5A	1275VA, 1147W, 11.6A
100VAC input	850VA, 765W, 8.5A	1200VA, 1147W, 12A	750VA, 675W, 7.5A	935VA, 842W, 9.4A	1200VA, 1147W, 12A
Dimensions and Weights					
Unit Dimensions, W x D x H, in. (mm)	17.2 x 20.1 x 1.7 (438 x 450 x 44)	17.2 x 24.8 x 1.7 (438 x 631 x 44)	5.7 x 14.8 x 8.7 (145 x 370 x 220)		5.7 x 19.1 x 8.7 (145 x 484 x 220)
Shipping Dimensions, W x D x H, in (mm)	22.1 x 23.4 x 5.5 (560 x 595 x 140)	23.4 x 27.8 x 5.5 (595 x 710 x 140)	9.1 x 17.7 x 12.8 (230 x 450 x 325)		9.1 x 22.4 x 12.8 (230 x 570 x 325)
Unit Weight, lb. (kg)	36.4 (16.5)	45.6 (20.7)	24.7 (11.2)	26.0 (11.8)	40.1 (18.2)
Shipping Weight, lb. (kg)	40.8 (18.5)	51.1 (23.2)	27.8 (12.6)	29.1 (13.2)	44.1 (20.0)
Input					
Voltage Input Range (with battery operation)	0~150VAC				
Voltage Input Range (without battery operation)	75~146VAC				
Input Voltage Measurement Tolerance	3%	3%	3%	3%	3%
Nominal Voltage Setting	100 / 110 / 115 / 120 / 125VAC				
High Line Buck to Battery	117 / 129 / 135 / 140 / 146VAC				
High Line Battery to Buck	114 / 125 / 131 / 137 / 143VAC				
High Line Normal to Buck	110 / 121 / 127 / 132 / 138VAC				
High Line Buck to Normal	107 / 118 / 123 / 128 / 134VAC				
Low Line Boost to Normal	93 / 102 / 107 / 112 / 116VAC				
Low Line Normal to Boost	90 / 99 / 104 / 108 / 113VAC				
Low Line Battery to Boost	80 / 88 / 92 / 96 / 100VAC				
Low Line Boost to Battery	75 / 83 / 86 / 90 / 94VAC				
Frequency Input Range	55~65 Hz (57~63 Hz Battery to Normal comeback)				
Internal Rear Panel Input Breaker Rating	13A	16A	10A	13A	16A
Input Surge Protection	ANSI C62.41, Category A, Level 3 1372 J				

Table 5.2 PS15 Specifications for 1U and MT Models (continued)

	PS15-1000RM1201U	PS15-1500RM1201U	PS15-750MT120	PS15-1100MT120	PS15-1500MT120
Input Power Cord	NEMA 5-15P, offset 90-degree type (3m attached)				
Output					
Output Voltages (on battery)	100 / 110 / 115 / 120 / 125VAC (± 1.5 on battery before alarm) user selectable (120VAC is factory default)				
Output Frequency (on battery)	60 Hz $\pm 1\%$				
Output Receptacles - not controllable	(3) NEMA 5-15R				
Output Receptacles - controllable	(2) NEMA 5-15R (3) NEMA 5-15R				
Transfer Time	Adjustable with User Setting 09 ST1: 4-6 ms typical, 10 ms max. (default) ST2: 6-8 ms typical, 11ms max. ST3: 8-10 ms typical, 13 ms max.				
Output Waveform (on Battery)	Pure Sinewave				
Output Overload Operation	100% - alarm warning 110% - alarm warning and shutdown after 10 seconds 120% - alarm warning and immediate shutdown				
Protection	Electronic (overcurrent, short circuit w/ latching shutdown)				
AC Mode Efficiency	98%				
Buck and Boost Mode Efficiency	93%				
Recharge Time	6 hours to recover to 90% 6-8 hours to recover to 90%				
Internal Battery					
Part Number	PS15-10001UBATKIT	PS15-15001UBATKIT	PS15-750MTBATKIT	PS15-1100MTBATKIT	PS15-1500MTBATKIT
Protection	Electronic (overcurrent, short circuit with latching shutdown)				
Type	Valve-regulated, lead-acid (VRLA) in compliance with UL 1989				
Battery Manufacturer/Model	CSB/RUM6290	CSB/RUM6290	Leoch/DJW12-9.0 CSB/HR1234W	Leoch/DJW12-10 CSB/UPS12580	Leoch/DJW12-9.0 CSB/HR1234W
Quantity x Voltage x Ah	4 x 6V x 9Ah	6 x 6V x 9Ah	2 x 12V x 9Ah	2 x 12V x 10Ah	4 x 12V x 9Ah
Environmental Requirements					
Operating Temperature, °F (°C)	32 - 104 (0 - 40)				
Operating Elevation, ft. (m)	0 - 9,942 (0 - 3,000) without derating Operating temperature reduced 9°F (5°C) for each additional 1,640 ft (500 m) of altitude.				
Relative Humidity	20% to 90% non-condensing				
Storage Temperature	-5°F - 122°F (-15°C - 50°C)				
Storage Relative Humidity	20% to 90% non-condensing				
Audible Noise	< 45 dB		< 45 dB @ Line mode < 55 dB @ Battery mode		

Table 5.3 PS15 Specifications for LI Models

	PS15-1600RT20LI	PS15-3000RT20LI
Power Rating		
125VAC input	1500VA, 1350W, 12A	3000VA, 2700W, 24A
120VAC input	1440VA, 1350W, 12A	2880VA, 2700W, 24A
115VAC input	1380VA, 1350W, 12A	2760VA, 2700W, 24A
110VAC input	1275VA, 1147W, 11.6A	2550VA, 2295W, 23.2A
100VAC input	1200VA, 1147W, 12A	2400VA, 2295W, 24A
Dimensions and Weights		
Unit Dimensions, W x D x H, in. (mm)	410 x 438 x 88	630 x 438 x 88
Shipping Dimensions, W x D x H, in (mm)	582 x 258 x 570	782 x 258 x 570
Unit Weight, lb. (kg)	12.9	24.3
Shipping Weight, lb. (kg)	19.1	30.8
Input		
Voltage Input Range (with battery operation)		0~150VAC
Voltage Input Range (without battery operation)		75~146VAC
Input Voltage Measurement Tolerance		3%
Nominal Voltage Setting, VAC	100 / 110 / 115 / 120 / 125	
High Line Buck to Battery, VAC	117 / 129 / 135 / 140 / 146	
High Line Battery to Buck, VAC	114 / 125 / 131 / 137 / 143	
High Line Normal to Buck, VAC	110 / 121 / 127 / 132 / 138	
High Line Buck to Normal, VAC	107 / 118 / 123 / 128 / 134	
Low Line Boost to Normal, VAC	93 / 102 / 107 / 112 / 113	
Low Line Normal to Boost, VAC	90 / 99 / 104 / 108 / 116	
Low Line Battery to Boost, VAC	80 / 88 / 92 / 96 / 100	
Low Line Boost to Battery, VAC	75 / 83 / 86 / 90 / 94	
Frequency Input Range	55~65 Hz (57~63 Hz Battery to Normal comeback)	
Internal Rear Panel Input Breaker Rating	13A	16A

Table 5.3 PSi5 Specifications for LI Models (continued)

	PSi5-1500RT120LI	PSi5-3000RT120LI
Input Surge Protection	ANSI C62.41, Category A, Level 3 1372 J	
Input Power Cord	NEMA 5-15P, offset 90-degree type (3m attached)	
Output	NEMA L5-30P (3m attached)	
Output Voltages (on battery)	100 / 110 / 115 / 120 / 125VAC (± 1.5 on battery before alarm) user selectable (120VAC is factory default)	
Output Frequency (on battery)	60 (default) / 50 Hz $\pm 1\%$	
Output Receptacles - not controllable	(3) NEMA 5-15R	(3) NEMA 5-15/20R, (1) NEMA L5-30R
Output Receptacles - controllable	(3) NEMA 5-15R	(3) NEMA 5-15/20R
Transfer Time	Adjustable with User Setting 09	ST1: 4-6 ms typical, 10 ms max. (default)
ST2: 6-8 ms typical, 11ms max.	ST3: 8-10 ms typical, 13 ms max. "	Output Waveform (on Battery) Pure Sinewave
Output Overload Operation "100% - alarm warning"	110% - alarm warning and shutdown after 10 seconds	120% - alarm warning and immediate shutdown"
Protection	Electronic (overcurrent, short circuit w/ latching shutdown)	
AC Mode Efficiency	97%	
Buck and Boost Mode Efficiency	94%	
Recharge Time (typical)	2 hours to recover to 100%	3 hours to recover to 100%
Internal Battery		
Part Number	PSi5-1500LIBATKIT	PSi5-3000LIBATKIT
Protection	Electronic (overcurrent, short circuit with latching shutdown)	
Type	LiFePO4 Battery in compliance with UL 1973 and UL 1642	
Battery Manufacturer	DLG	
Quantity x Battery Model	1x LiFe-485000	3x LiFe-722500
Environmental Requirements		
Operating Temperature, °F (°C)	32 - 104 (0 - 40)	
Operating Elevation, ft. (m)	0 - 9,942 (0 - 3,000) without derating. Operating temperature reduced 9°F (5°C) for each additional 1,640 ft (500 m) of altitude.	
Relative Humidity	20% to 90% non-condensing	
Storage Temperature	-5°F - 122°F (-15°C - 50°C)	
Storage Relative Humidity	10% to 90% non-condensing	

Table 5.3 PS15 Specifications for LI Models (continued)

	PS15-1500RT120LI	PS15-3000RT120LI
Audible Noise	< 45 dB @ Line mode, < 55 dB @ Battery mode	
Internal Battery		
Part Number	PS15-1500LIBATKIT	PS15-3000LIBATKIT
Protection	Electronic (overcurrent, short circuit with latching shutdown)	
Type	LiFePO4 Battery in compliance with UL 1973 and UL 1642	
Battery Manufacturer	DLG	
Quantity x Battery Model	1x LiFe-485000	3x LiFe-722500
Environmental Requirements		
Operating Temperature, °F (°C)	32 - 104 (0 - 40)	
Operating Elevation, ft. (m)	0 - 9,942 (0 - 3,000) without derating; Operating temperature reduced 9°F (5°C) for each additional 1,640 ft (500 m) of altitude.	
Relative Humidity	20% to 90% non-condensing	
Storage Temperature	-5°F - 122°F (-15°C - 50°C)	
Storage Relative Humidity	10% to 90% non-condensing	
Audible Noise	< 45 dB @ Line mode, < 55 dB @ Battery mode	

5.1 Run Times

NOTE: Liebert® PSI5-1100/2200/3000/5000: When using 2 or more external battery cabinets (EBCs) the UPS load rating will be decreased by 20%. The % load graph on the LCD automatically adjusts to reflect this derating.

NOTE: Run times are approximate. They are based on new, fully charged batteries at a temperature of 25°C (77°F) with 100% resistive UPS loading.

Table 5.4 PSI5-800RT120

LOAD			NUMBER OF EXTERNAL BATTERY CABINETS						
			INTERNAL BATTERY ONLY	1	2	3	4	5	6
%	VA	W	MINUTES						
100	800	720	5.5	27	51	76	104	132	161
90	720	648	6.5	31	58	87	118	150	183
80	640	576	8.0	36	67	101	136	173	210
70	560	504	10.0	42	79	118	160	202	246
60	480	432	12.5	51	96	144	193	244	295
50	400	360	16.0	64	119	178	239	300	363
40	320	288	21.5	84	155	230	306	384	462
30	240	216	30.5	116	213	313	415	517	620
20	160	144	44.0	167	303	441	581	721	862
10	80	72	85.5	313	552	792	1034	1276	1519

Table 5.5 PSI5-1100RT120

LOAD					NUMBER OF EBCS		LOAD						
					INTERNAL BATTERY ONLY	1							
%	VA	W	MINUTES		%	VA	W	MINUTES					
100	1100	990	4.5	20	100	880	792	48	71	95	120	147	
90	990	891	5.5	23	90	792	713	54	81	109	138	167	
80	880	792	6.5	27	80	704	634	63	94	126	159	193	
70	770	693	8.5	32	70	616	554	75	111	149	188	228	
60	660	594	11.0	39	60	528	475	91	134	179	226	273	
50	550	495	13.5	48	50	440	396	113	167	222	279	336	
40	440	396	18.5	63	40	352	317	147	216	286	357	429	
30	330	297	27.0	89	30	264	238	205	298	393	488	584	
20	220	198	40.0	131	20	176	158	294	423	553	684	816	
10	110	99	87.0	278	10	88	79	545	774	1003	1233	1463	

Table 5.6 Liebert® PSI5-1500RT120

LOAD			NUMBER OF EXTERNAL BATTERY CABINETS						
			INTERNAL BATTERY ONLY	1	2	3	4	5	6
%	VA	W	MINUTES						
100	1500	1350	6.0	30	56	84	114	145	176
90	1350	1215	7.5	34	64	96	130	165	200
80	1200	1080	9.0	40	74	111	150	191	231
70	1050	945	11.0	47	87	131	177	224	271
60	900	810	14.0	57	106	158	213	268	324
50	750	675	18.0	71	131	196	262	329	396
40	600	540	24.0	93	172	254	338	423	508
30	450	405	34.0	130	237	348	461	574	687
20	300	270	50.0	190	341	496	651	807	964
10	150	135	110.5	398	695	994	1294	1594	1895

Table 5.7 PSI5-2200RT120

LOAD			NUMBER OF EBCS		LOAD			NUMBER OF EBCS				
			INTERNAL BATTERY ONLY	1				2	3	4	5	6
%	VA	W	MINUTES		%	VA	W	MINUTES				
100	1920	1920	5.0	27	100	1536	1536	72	111	152	194	237
90	1728	1728	6.0	32	90	1382.4	1382	83	127	174	222	270
80	1536	1536	7.0	37	80	1228.8	1229	96	147	201	255	310
70	1344	1344	8.5	44	70	1075.2	1075	113	173	235	298	362
60	1152	1152	11.0	53	60	921.6	922	137	208	281	356	430
50	960	960	14.0	63	50	768	768	164	248	334	421	508
40	768	768	18.5	87	40	614.4	614	220	330	442	554	667
30	576	576	27.0	123	30	460.8	461	303	450	598	748	897
20	384	384	40.0	177	20	307.2	307	423	624	825	1027	1230
10	192	192	88.0	343	10	153.6	154	808	1174	1542	1909	2277

Table 5.8 Liebert® PSI5-3000RT120

LOAD			NUMBER OF EBCS		LOAD			NUMBER OF EBCS				
			INTERNAL BATTERY ONLY	1				2	3	4	5	6
%	VA	W	MINUTES		%	VA	W	MINUTES				
100	3000	2700	5.5	22	100	2400	2160	54	81	109	138	167
90	2700	2430	6.5	26	90	2160	1944	62	92	124	157	190
80	2400	2160	8.0	30	80	1920	1728	72	107	143	181	219
70	2100	1890	10.0	36	70	1680	1512	85	126	169	213	258
60	1800	1620	12.8	43	60	1440	1296	103	152	203	255	308
50	1500	1350	16.0	54	50	1200	1080	129	189	251	315	378
40	1200	1080	22.0	72	40	960	864	168	245	324	404	484
30	900	810	32.0	101	30	720	648	233	338	444	551	658
20	600	540	46.0	145	20	480	432	327	470	613	758	902
10	300	270	103.0	313	10	240	216	653	923	1195	1466	1738

Table 5.9 PSI5-5000RT208

LOAD			NUMBER OF EBCS		LOAD			NUMBER OF EBCS				
			INTERNAL BATTERY ONLY	1				2	3	4	5	6
%	VA	W	MINUTES		%	VA	W	MINUTES				
100	4250	3825	3	15	100	4000	3600	30	45	60	76	93
90	3825	3443	4	17	90	3600	3240	35	51	69	87	106
80	3400	3060	5	20	80	3200	2880	40	59	79	100	122
70	2975	2678	6	24	70	2800	2520	47	70	93	118	144
60	2550	2295	8	29	60	2400	2160	57	84	113	142	173
50	2125	1913	10	36	50	2000	1800	70	104	139	175	212
40	1700	1530	14	48	40	1600	1440	92	136	181	227	274
30	1275	1178	21	67	30	1200	1080	128	188	249	311	374
20	850	765	34	106	20	800	720	199	288	378	470	560
10	425	383	69	215	10	400	360	358	511	665	819	974

Table 5.10 PSI5-1000RM1201U

LOAD			MINUTES
%	VA	W	
100	1000	900	5.1
90	900	810	5.8
80	800	720	6.9
70	700	630	8.3
60	600	540	10.4
50	500	450	13.4
40	400	360	18.2
30	300	270	26.9
20	200	180	41.9
10	100	90	90.6

Table 5.11 PSI5-1500RM1201U

LOAD			MINUTES
%	VA	W	
100	1500	1350	5.1
90	1350	1215	5.9
80	1200	1080	7.1
70	1050	945	8.5
60	900	810	10.6
50	750	675	13.5
40	600	540	18.4
30	450	405	26.9
20	300	270	41.6
10	150	135	91.2

Table 5.12 PSI5-750MT120

LOAD			MINUTES
%	VA	W	
100	750	675	6.1
90	675	607.5	7.3
80	600	540	8.8
70	525	472.5	10.9
60	450	405	13.8
50	375	337.5	17.7
40	300	270	23.5
30	225	202.5	33.0
20	150	135	48.0
10	75	67.5	92.5

Table 5.13 PSI5-1100MT120

LOAD			MINUTES
%	VA	W	
100	1100	990	4.6
90	990	891	5.6
80	880	792	6.8
70	770	693	8.5
60	660	594	11.0
50	550	495	13.7
40	440	396	18.8
30	330	297	27.5
20	220	198	45.5
10	110	99	107.0

Table 5.14 PSI5-1500MT120

LOAD			MINUTES
%	VA	W	
100	1500	1350	6.3
90	1350	1215	7.5
80	1200	1080	9.1
70	1050	945	11.2
60	900	810	14.1
50	750	675	18.1
40	600	540	24.2
30	450	405	34.2
20	300	270	50.4
10	150	135	110.9

Table 5.15 PSI5-1500RT120LI

LOAD			MINUTES
%	VA	W	
100	1500	1350	7.5
90	1350	1215	8.9
80	1200	1080	10.3
70	1050	945	12.1
60	900	810	14.6
50	750	675	17.7
40	600	540	22.8
30	450	405	30.6
20	300	270	45.3
10	150	135	89.0

Table 5.16 PSI5-3000RT120LI

LOAD			MINUTES
%	VA	W	
100	3000	2700	8.9
90	2700	2430	10.5
80	2400	2160	11.9
70	2100	1890	13.9
60	1800	1620	16.5
50	1500	1350	20.0
40	1200	1080	25.5
30	900	810	34.2
20	600	540	49.1
10	300	270	96.6





Vertiv.com | Vertiv Headquarters, 1050 Dearborn Drive, Columbus, OH, 43085, USA

© 2020 Vertiv Group Corp. All rights reserved. Vertiv and the Vertiv logo are trademarks or registered trademarks of Vertiv Group Corp. All other names and logos referred to are trade names, trademarks or registered trademarks of their respective owners. While every precaution has been taken to ensure accuracy and completeness herein, Vertiv Group Corp. assumes no responsibility, and disclaims all liability, for damages resulting from use of this information or for any errors or omissions. Specifications are subject to change without notice.

SL-23314_REV8_01_20