



# TABLE OF CONTENTS

---

## Chapter 1 - Getting Started

<b>Introduction</b> .....	1-2
The Purpose of this Manual.....	1-2
Where to Begin .....	1-2
Supplemental Manuals .....	1-2
Technical Support.....	1-2
<b>Conventions Used</b> .....	1-3
Key Topics for Each Chapter.....	1-3
DL105 Micro PLC Components.....	1-4
The DL105 Micro PLC Family .....	1-4
<b>Programming Methods</b> .....	1-5
<i>Direct</i> SOFT Programming for Windows .....	1-5
Handheld Programmer.....	1-5
<b>I/O Quick Chart Selection</b> .....	1-6
<b>Quick Start for PLC Checkout and Programming</b> .....	1-7
Step 1: Unpack the Recommended DL105 Equipment.....	1-7
Step 2: Connect Switches to Input Terminals .....	1-8
F1-130AR, F1-130AD, F1-130AA.....	1-8
F1-130DR, F1-130DD-D .....	1-8
Step 3: Connect the Power Wiring .....	1-9
Step 4: Connect the Programming Device .....	1-9
Step 5: Switch on the System Power .....	1-10
Step 6: Initialize Scratchpad Memory .....	1-10
Step 7: Enter a Ladder Program .....	1-10
<b>Steps to Designing a Successful System</b> .....	1-11
Step 1: Review the Installation Guidelines .....	1-11
Step 2: Understand PLC Setup Procedures .....	1-11
Step 3: Review the I/O Selection Criteria.....	1-11

Step 4: Choose a System Wiring Strategy.....	1-11
Step 5: Understand the System Operation .....	1-11
Step 6: Review the Programming Concepts .....	1-12
Step 7: Choose the Instructions.....	1-12
Step 8: Understand the Maintenance and Troubleshooting Procedures.....	1-12
<b>Questions and Answers about DL105 Micro PLCs.....</b>	<b>1-13</b>

## Chapter 2 –Installation, Wiring and Specifications

<b>Safety Guidelines .....</b>	<b>2-2</b>
Plan for Safety .....	2-2
Safety Techniques.....	2-2
Three Levels of Protection .....	2-3
Emergency Stops.....	2-3
Emergency Power Disconnect .....	2-4
Orderly System Shutdown .....	2-4
Class 1, Division 2 Approval .....	2-4
<b>Orientation to DL105 Front Panel .....</b>	<b>2-5</b>
Accessing the I/O Terminals .....	2-5
Protective Sheet for DL105 Vents .....	2-6
Connector Removal.....	2-6
<b>Mounting Guidelines.....</b>	<b>2-7</b>
Unit Dimensions.....	2-7
Enclosures .....	2-7
Panel Layout & Clearances .....	2-8
Agency Approvals.....	2-9
Environmental Specifications .....	2-9
Using Mounting Rails .....	2-10
<b>Wiring Guidelines .....</b>	<b>2-11</b>
Power Input Wiring .....	2-11
Fuse Protection for Input Power .....	2-11
External Power Source.....	2-12
Planning the Wiring Routes .....	2-13
Fuse Protection for Input and Output Circuits .....	2-13
I/O Point Numbering .....	2-14

<b>System Wiring Strategies</b> .....	<b>2-14</b>
PLC Isolation Boundaries .....	2-14
Powering I/O Circuits with the Auxiliary Supply .....	2-16
Powering I/O Circuits Using Separate Supplies .....	2-17
Connecting Operator Interface Devices .....	2-18
Connecting Programming Devices .....	2-18
Sinking / Sourcing Concepts .....	2-19
I/O “Common” Terminal Concepts .....	2-20
Connecting DC I/O to “Solid State” Field Devices .....	2-21
Solid State Input Sensors .....	2-21
Surge Suppression For Inductive Loads .....	2-24
Prolonging Relay Contact Life .....	2-25
DC Output Wiring Methods .....	2-27
High-Speed I/O Wiring Methods .....	2-28
F1-04SIM Input Simulator Wiring .....	2-29
<b>Wiring Diagrams and Specifications</b> .....	<b>2-30</b>
F1-130AR I/O Wiring Diagram .....	2-30
Auxiliary +24V Power Supply .....	2-31
F1-130AR General Specifications .....	2-31
F1-130AR Relay Output Specifications .....	2-32
F1-130DR/ F1-130DR-CE I/O Wiring Diagram .....	2-33
Auxiliary +24V Power Supply .....	2-34
F1-130DR/ F1-130DR-CE Relay Output Specifications .....	2-35
F1-130AD I/O Wiring Diagram .....	2-36
Auxiliary +24V Power Supply .....	2-36
F1-130AD General Specifications .....	2-37
F1-130AD I/O DC Output Specifications .....	2-38
F1-130DD/ F1-130DD-CE I/O Wiring Diagram .....	2-39
Auxiliary +24V Power Supply .....	2-39
F1-130DD/ F130-DD-CE General Specifications .....	2-40
F1-130DD/ F130-DD-CE DC Output Specifications .....	2-41
F1-130AA I/O Wiring Diagram .....	2-42
Auxiliary +24V Power Supply .....	2-42
F1-130AA General Specifications .....	2-43
F1-130AA I/O DC Output Specifications .....	2-44
F1-130DA I/O Wiring Diagram .....	2-45

## Table of Contents

---

Auxiliary +24V Power Supply.....	2-45
F1-130DA General Specifications .....	2-46
F1-130DA AC Output Specifications .....	2-47
F1-130DR-D I/O Wiring Diagram .....	2-48
No Auxiliary +24V Power Supply.....	2-48
F1-130DR-D General Specifications .....	2-49
F1-130DR/ F1-130DR-CE Relay Output Specifications .....	2-50
F1-130DD-D I/O Wiring Diagram.....	2-51
No Auxiliary +24V Power Supply .....	2-51
F1-130DD-D General Specifications.....	2-52
F1-130DD-D DC Output Specifications .....	2-53
<b>Glossary of Specification Terms .....</b>	<b>2-54</b>

## Chapter 3 - High-Speed Input and Pulse Output Features

<b>Introduction.....</b>	<b>3-2</b>
Built-in Motion Control Solution .....	3-2
Dedicated High- Speed I/O Circuit.....	3-3
Wiring Diagrams for Each HSIO Mode.....	3-3
<b>Choosing the HSIO Operating Mode.....</b>	<b>3-4</b>
Understanding the Six Modes .....	3-4
Default Mode.....	3-4
Configuring the HSIO Mode .....	3-5
Configuring Inputs X0-X3.....	3-5
<b>Mode 10: High-Speed Counter .....</b>	<b>3-6</b>
Purpose.....	3-6
Functional Block Diagram.....	3-6
Wiring Diagram.....	3-7
Interfacing to Counter Outputs.....	3-7
Setup for Mode 10.....	3-8
Preset Data Starting Location .....	3-9
Using Fewer than 24 Presets .....	3-9
Equal Relay Numbers .....	3-9
Calculating Your Preset Values.....	3-10
X Input Configuration .....	3-10
Writing Your Control Program.....	3-11

Program Example: Counter Without Preset .....	3-11
Counter With Presets Program Example .....	3-13
Counter With Preload Program Example .....	3-15
Troubleshooting Guide for Mode 10 .....	3-16
<b>Mode 20: Quadrature Counter .....</b>	<b>3-17</b>
Purpose .....	3-17
Functional Block Diagram.....	3-17
Quadrature Encoder Signals .....	3-17
Wiring Diagram.....	3-18
Interfacing to Encoder Outputs .....	3-18
Setup for Mode 20.....	3-19
X Input Configuration .....	3-19
Writing Your Control Program.....	3-20
Quadrature Counter w/Preload Program Example.....	3-20
Counter Preload Program Example.....	3-22
Troubleshooting Guide for Mode 20 .....	3-22
<b>Mode 30: Pulse Output .....</b>	<b>3-23</b>
Functional Block Diagram.....	3-24
Wiring Diagram.....	3-25
Interfacing to Drive Inputs.....	3-25
Motion Profile Specifications .....	3-26
Physical I/O Configuration.....	3-26
Logical I/O Functions .....	3-26
Setup for Mode 30.....	3-27
Profile / Velocity Select Register.....	3-27
Profile Parameter Table.....	3-28
Trapezoidal Profile .....	3-28
Registration Profile .....	3-28
Velocity Profile.....	3-28
Choosing the Profile Type .....	3-29
Trapezoidal Profile Defined .....	3-29
Registration and Home Search Profiles Defined .....	3-29
Velocity Profile Defined.....	3-29
<b>Trapezoidal Profile Operation.....</b>	<b>3-30</b>
Trapezoidal Profile Applications .....	3-30
Trapezoidal Profile Program Example.....	3-31

## Table of Contents

---

<b>Registration Profile Operation .....</b>	<b>3-33</b>
Registration Applications .....	3-33
Registration Profile Program Example .....	3-34
Home Search Program Example .....	3-36
<b>Velocity Profile Operation .....</b>	<b>3-38</b>
Velocity Profile Program Example .....	3-39
Pulse Output Error Codes .....	3-41
Troubleshooting Guide for Mode 30 .....	3-41
<b>Mode 40: High-Speed Interrupts .....</b>	<b>3-43</b>
Setup for Mode 40 .....	3-44
Interrupts and the Ladder Program .....	3-44
External Interrupt Timing Parameters .....	3-45
Timed Interrupt Parameters .....	3-45
X Input / Timed INT Configuration .....	3-45
External Interrupt Program Example .....	3-46
Timed Interrupt Program Example .....	3-47
<b>Mode 50: Pulse Catch Input .....</b>	<b>3-48</b>
Purpose .....	3-48
Functional Block Diagram .....	3-48
Pulse Catch Timing Parameters .....	3-48
Setup for Mode 50 .....	3-49
X Input Configuration .....	3-49
Pulse Catch Program Example .....	3-50
Mode 60: Discrete Inputs with Filter .....	3-51
Purpose .....	3-51
Functional Block Diagram .....	3-51
Input Filter Timing Parameters .....	3-51
Setup for Mode 60 .....	3-52
X Input Configuration .....	3-52
Filtered Inputs Program Example .....	3-53

## Chapter 4 - CPU Specifications and Operation

<b>Introduction .....</b>	<b>4-2</b>
DL105 CPU Features .....	4-2
<b>CPU Specifications .....</b>	<b>4-3</b>

<b>CPU Hardware Setup</b> .....	4-4
Communication Port Pinout Diagrams .....	4-4
Connecting the Programming Devices .....	4-5
CPU Setup Information .....	4-5
CPU Modes .....	4-6
Mode of Operation at Power-up .....	4-6
Changing Modes in the DL105 PLC .....	4-6
Setting Bits in V7633.....	4-7
Auxiliary Functions .....	4-8
Clearing an Existing Program .....	4-9
Initializing System Memory .....	4-9
Setting Retentive Memory Ranges.....	4-9
Using a Password .....	4-10
CPU Operating System.....	4-11
Program Mode.....	4-12
Run Mode .....	4-12
Read Inputs .....	4-13
Service Peripherals and Force I/O .....	4-13
Update Special Relays and Special Registers .....	4-13
Solve Application Program .....	4-14
Write Outputs .....	4-14
Diagnostics.....	4-14
<b>I/O Response Time</b> .....	4-15
Is Timing Important for Your Application? .....	4-15
Normal Minimum I/O Response.....	4-15
Normal Maximum I/O Response .....	4-16
Improving Response Time .....	4-17
<b>CPU Scan Time Considerations</b> .....	4-18
Reading Inputs .....	4-18
Writing Outputs .....	4-18
Application Program Execution .....	4-19
<b>PLC Numbering Systems</b> .....	4-20
PLC Resources .....	4-20
V- Memory .....	4-21
Binary-Coded Decimal Numbers .....	4-21
Hexadecimal Numbers .....	4-21

## Table of Contents

---

<b>Memory Map</b> .....	4-22
Octal Numbering System .....	4-22
Discrete and Word Locations .....	4-22
V-memory Locations for Discrete Memory Areas .....	4-22
Input Points (X Data Type) .....	4-23
Output Points (Y Data Type) .....	4-23
Control Relays (C Data Type) .....	4-23
Timers and Timer Status Bits (T Data type).....	4-23
Timer Current Values (V Data Type) .....	4-24
Counters and Counter Status Bits (CT Data type) .....	4-24
Counter Current Values (V Data Type).....	4-24
Word Memory (V Data Type) .....	4-25
Stages (S Data type).....	4-25
Special Relays (SP Data Type).....	4-25
<b>DL105 System V-memory</b> .....	4-26
System Parameters and Default Data Locations (V Data Type).....	4-26
<b>DL105 Aliases</b> .....	4-28
DL105 Memory Map.....	4-29
<b>X Input Bit Map</b> .....	4-30
<b>Y Output Bit Map</b> .....	4-30
<b>Control Relay Bit Map</b> .....	4-30
<b>Stage Control / Status Bit Map</b> .....	4-31
<b>Timer Status Bit Map</b> .....	4-31
<b>Counter Status Bit Map</b> .....	4-32

## Chapter 5 - Standard RLL Instructions

<b>Introduction</b> .....	5-2
<b>Using Boolean Instructions</b> .....	5-4
END Statement .....	5-4
Simple Rungs .....	5-4
Normally Closed Contact .....	5-5
Contacts in Series.....	5-5



Mid-line Outputs.....	5-5
Parallel Elements.....	5-6
Joining Series Branches in Parallel.....	5-6
Joining Parallel Branches in Series.....	5-6
Combination Networks .....	5-6
Comparative Boolean .....	5-7
Boolean Stack.....	5-7
Immediate Boolean .....	5-8
<b>Boolean Instructions .....</b>	<b>5-9</b>
<b>Comparative Boolean .....</b>	<b>5-18</b>
<b>Immediate Instructions .....</b>	<b>5-24</b>
<b>Timer, Counter and Shift Register Instructions .....</b>	<b>5-29</b>
Using Timers .....	5-29
Timer Example Using Discrete Status Bits .....	5-31
Accumulating Timer (TMRA) .....	5-32
Accumulating Timer Example using Discrete Status Bits .....	5-33
Accumulator Timer Example Using Comparative Contacts .....	5-33
Counter Example Using Discrete Status Bits .....	5-36
Counter Example Using Comparative Contacts .....	5-36
Stage Counter Example Using Discrete Status Bits.....	5-38
Stage Counter Example Using Comparative Contacts .....	5-38
Up/Down Counter Example Using Discrete Status Bits .....	5-40
Up/Down Counter Example Using Comparative Contacts.....	5-40
<b>Accumulator/Stack Load and Output Data Instructions .....</b>	<b>5-42</b>
Using the Accumulator.....	5-42
Copying Data to the Accumulator.....	5-42
Changing the Accumulator Data.....	5-43
Using the Accumulator Stack.....	5-44
Using Pointers .....	5-46
Load (LD).....	5-47
<b>Logical Instructions (Accumulator) .....</b>	<b>5-55</b>
Exclusive OR Double (XORD) .....	5-60
<b>Math Instructions .....</b>	<b>5-63</b>
Subtract (SUB).....	5-65

## Table of Contents

---

Subtract Double (SUBD).....	5-66
Multiply (MUL).....	5-67
Divide (DIV) .....	5-68
Increment Binary (INCB) .....	5-69
Decrement Binary (DECB) .....	5-69
<b>Bit Operation Instructions.....</b>	<b>5-70</b>
Shift Left (SHFL) .....	5-70
Shift Right (SHFR).....	5-71
Encode (ENCO).....	5-72
Decode (DECO) .....	5-73
<b>Number Conversion Instructions (Accumulator).....</b>	<b>5-74</b>
Binary (BIN) .....	5-74
Binary Coded Decimal (BCD) .....	5-75
Invert (INV) .....	5-76
<b>Table Instructions .....</b>	<b>5-77</b>
Move (MOV).....	5-77
Move Memory Cartridge (MOVMC).....	5-78
Load Label (LDLBL) .....	5-78
Copy Data From a Data Label Area to V-Memory.....	5-79
<b>CPU Control Instructions.....</b>	<b>5-80</b>
No Operation (NOP).....	5-80
End (END).....	5-80
Stop (STOP) .....	5-80
<b>Program Control Instructions .....</b>	<b>5-81</b>
Master Line Set (MLS) .....	5-81
Master Line Reset (MLR).....	5-81
Understanding Master Control Relays.....	5-81
MLS/MLR Example .....	5-82
<b>Interrupt Instructions .....</b>	<b>5-83</b>
Interrupt (INT).....	5-83
Interrupt Return (IRT) .....	5-83
Interrupt Return Conditional (IRTC).....	5-83
Enable Interrupts (ENI) .....	5-83
Disable Interrupts (DISI) .....	5-83

External Interrupt Program Interrupt ..... 5-84

**Message Instructions ..... 5-85**

    Fault (FAULT)..... 5-85

    Fault Example..... 5-86

    Data Label (DLBL) ..... 5-87

    ASCII Constant (ACON) ..... 5-87

    Numerical Constant (NCON) ..... 5-87

    Data Label Example..... 5-88

## Chapter 6 - Drum Instruction Programming

**Introduction ..... 6-2**

    Purpose ..... 6-2

    Drum Terminology ..... 6-2

    Drum Chart Representation..... 6-3

    Output Sequences..... 6-3

**Step Transitions ..... 6-4**

    Drum Instruction Parameters..... 6-4

    Timer and Event Transitions..... 6-5

    Event-Only Transitions ..... 6-6

    Counter Assignments ..... 6-6

    Last Step Completion ..... 6-7

**Overview of Drum Operation ..... 6-8**

    Drum Instruction Block Diagram ..... 6-8

    Powerup State of Drum Registers ..... 6-9

**Drum Control Techniques ..... 6-10**

    Drum Control Inputs..... 6-10

    Self-Resetting Drum..... 6-11

    Initializing Drum Outputs..... 6-11

    Using Complex Event Step Transitions..... 6-11

**Drum Instructions ..... 6-12**

    Handheld Programmer Drum Mnemonics..... 6-14

## Chapter 7 - RLL<sup>Plus</sup> Stage Programming

Introduction to Stage Programming ..... 7-2

## Table of Contents

---

Overcoming “Stage Fright” .....	7-2
<b>Learning to Draw State Transition Diagrams .....</b>	<b>7-3</b>
Introduction to Process States .....	7-3
RLL Equivalent.....	7-4
Stage Equivalent.....	7-4
Let’s Compare .....	7-5
Initial Stages.....	7-5
What Stage Bits Do .....	7-6
Stage Instruction Characteristics.....	7-6
<b>Using the Stage Jump Instruction for State Transitions.....</b>	<b>7-7</b>
Stage Jump, Set, and Reset Instructions.....	7-7
<b>Stage Program Example: Toggle On/Off Lamp Controller .....</b>	<b>7-8</b>
<b>Four Steps to Writing a Stage Program .....</b>	<b>7-9</b>
<b>Stage Program Example: A Garage Door Opener.....</b>	<b>7-10</b>
Garage Door Opener Example .....	7-10
Add Safety Light Feature .....	7-12
<b>Stage Program Design Considerations .....</b>	<b>7-15</b>
Stage Program Organization .....	7-15
How Instructions Work Inside Stages .....	7-16
Using a Stage as a Supervisory Process.....	7-17
Stage Counter .....	7-17
Power Flow Transition Technique .....	7-18
Stage View in <i>Direct</i> SOFT .....	7-18
<b>RLL<sup>PLUS</sup> (Stage) Instructions.....</b>	<b>7-19</b>
Stage (SG).....	7-19
Initial Stage (ISG) .....	7-20
Jump (JMP).....	7-20
<b>Questions and Answers about Stage Programming .....</b>	<b>7-22</b>

## Chapter 8 - Maintenance and Troubleshooting

Hardware System Maintenance .....	8-2
Diagnostics.....	8-3

V-memory Error Code Locations.....	8-4
Special Relays (SP) Corresponding to Error Codes .....	8-4
DL105 Micro PLC Error Codes.....	8-5
Program Error Codes.....	8-6
<b>CPU Error Indicators.....</b>	<b>8-7</b>
<b>PWR Indicator .....</b>	<b>8-7</b>
Incorrect Base Power.....	8-7
Faulty CPU .....	8-7
Run Indicator.....	8-8
CPU Indicator.....	8-8
<b>Communications Problems .....</b>	<b>8-8</b>
<b>I/O Point .....</b>	<b>8-9</b>
Possible Causes .....	8-9
Some Quick Steps .....	8-9
Testing Output Points.....	8-10
Handheld Programmer Keystrokes Used to Test an Output Point .....	8-10
<b>Noise Troubleshooting .....</b>	<b>8-11</b>
Electrical Noise Problems.....	8-11
Reducing Electrical Noise.....	8-11
<b>Machine Startup and Program Troubleshooting .....</b>	<b>8-12</b>
Program Syntax Check.....	8-12
Special Instructions.....	8-13
Duplicate Reference Check.....	8-14
Run Time Edits .....	8-15
Forcing I/O Points .....	8-17
Reset the PLC to Factory Defaults .....	8-18

## Appendix A - Auxiliary Functions

<b>Introduction. ....</b>	<b>A-2</b>
Purpose of Auxiliary Functions.....	A-2
Accessing AUX Functions via DirectSOFT.....	A-3
Accessing AUX Functions via the Handheld Programmer.....	A-3
<b>AUX 2* — RLL Operations.....</b>	<b>A-4</b>
AUX 21 · Check Program .....	A-4

## Table of Contents

---

AUsX 22 · Change Reference.....	A-4
AUX 23 · Clear Ladder Range.....	A-4
AUX 24 · Clear Ladders .....	A-4
<b>AUX 3* — V-memory Operations.....</b>	<b>A-4</b>
AUX 31 · Clear V- Memory.....	A-4
<b>AUX 4* — I/O Configuration.....</b>	<b>A-5</b>
AUX 41 Show I/O Configuration .....	A-5
<b>AUX 5* — CPU Configuration .....</b>	<b>A-5</b>
AUX 51 · Modify Program Name.....	A-5
AUX 53 · Display Scan Time .....	A-5
AUX 54 · Initialize Scratchpad .....	A-5
AUX 55 · Set Watchdog Timer.....	A-5
AUX 57 · Set Retentive Ranges .....	A-6
AUX 58 · Test Operations .....	A-6
AUX 5B Counter Interface Configuration.....	A-6
<b>AUX 6* — Handheld Programmer Configuration .....</b>	<b>A-6</b>
AUX 61 · Show Revision Numbers.....	A-6
AUX 62 · Beeper On / Off .....	A-7
AUX 65 · Run Self Diagnostics.....	A-7
<b>AUX 7* — EEPROM Operations.....</b>	<b>A-7</b>
Transferable Memory Areas .....	A-7
AUX 71 · CPU to HPP EEPROM.....	A-7
AUX 72 · HPP EEPROM to CPU.....	A-7
AUX 73 · Compare HPP EEPROM to CPU .....	A-7
AUX 74 · HPP EEPROM Blank Check.....	A-8
AUX 75 · Erase HPP EEPROM.....	A-8
AUX 76 · Show EEPROM Type.....	A-8
<b>AUX 8* — Password Operations .....</b>	<b>A-8</b>
AUX 81 · Modify Password.....	A-8
AUX 82 · Unlock CPU.....	A-9
AUX 83 · Lock CPU .....	A-9

## Appendix B - DL105 Error Codes

DL105 Error Code Tables.....	B-2
------------------------------	-----

## Appendix C - Instruction Execution Times

<b>Introduction</b> .....	<b>C-2</b>
V-Memory Data Registers .....	C-2
V-Memory Bit Registers .....	C-2
How to Read the Tables.....	C-2
<b>Instruction Execution Times</b> .....	<b>C-3</b>
Boolean Instructions .....	C-3
Comparative Boolean Instructions, Continued.....	C-4
Comparative Boolean Instructions, Continued.....	C-5
Comparative Boolean Instructions, Continued.....	C-6
Immediate Instructions.....	C-6
Timer, Counter, Shift Register, EDRUM Instructions .....	C-7
Accumulator Data Instructions .....	C-8
Logical Instructions.....	C-9
Math Instructions .....	C-9
Bit Instructions .....	C-10
Number Conversion Instructions .....	C-10
Table Instructions .....	C-10
CPU Control Instructions.....	C-11
Program Control Instructions .....	C-11
Interrupt Instructions.....	C-11
Message Instructions.....	C-11
RLL <i>PLUS</i> Instructions .....	C-12

## Appendix D - Special Relays

<b>DL105 PLC Special Relays</b> .....	<b>D-2</b>
Startup and Real-Time Relays .....	D-2
CPU Status Relays.....	D-2
System Monitoring.....	D-3
Accumulator Status .....	D-3
Equal Relays for HSIO Mode 10 Counter Presets .....	D-4

## Appendix E - DL105 PLC Memory

<b>DL105 PLC Memory</b> .....	<b>E-2</b>
-------------------------------	------------

## Appendix F - European Union Directives (CE)

European Union (EU) Directives .....	F-2
General Safety .....	F-4
Other Sources of Information .....	F-4
<b>Basic EMC Installation Guidelines .....</b>	<b>F-5</b>
Enclosures .....	F-5
Electrostatic Discharge (ESD).....	F-5
Suppression and Fusing.....	F-6
Internal Enclosure Grounding .....	F-6
Equipotential Grounding .....	F-7
Communications and Shielded Cables .....	F-7
Analog and RS232 Cables .....	F-8
Shielded Cables within Enclosures .....	F-8
Analog Modules and RF Interference .....	F-9
Network Isolation .....	F-9
DC Powered Versions .....	F-9

## Appendix G - Numbering Systems

Introduction .....	G-2
Binary Numbering System .....	G-2
Hexadecimal Numbering System .....	G-3
Octal Numbering System .....	G-4
Binary Coded Decimal (BCD) Numbering System .....	G-5
Real (Floating Point) Numbering System .....	G-6
BCD/Binary/Decimal/Hex/Octal - What is the Difference? .....	G-7
Data Type Mismatch.....	G-8
Signed vs. Unsigned Integers.....	G-9
AutomationDirect.com Products and Data Types .....	G-10
<b>Direct</b> LOGIC PLCs.....	G-10
C-more and C-more Micro Graphic Panels.....	G-10