



# D-sub Feedthrough Module Installation Instructions

#### ZL-RTB-DB09 ZL-RTB-DB25 **ZL-RTB-DB15**
















NOTE: Pinouts are straight-through, pin to pin to terminal. Example: J1, Pin 1 to J2, Pin 1 to J3, Terminal 1, etc.




- A. THIS EQUIPMENT IS SUITABLE FOR USE IN CLASS I, DIVISION 2/ZONE 2, GROUPS A, B, C AND D OR NON-HAZARDOUS LOCATIONS ONLY.
- B. WARNING EXPLOSION HAZARD SUBSTITUTION OF COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS I, DIVISION 2/ZONE 2.
- C. WARNING EXPLOSION HAZARD DO NOT CONNECT OR DISCON-NECT CONNECTORS OR OPERATE SWITCHES WHILE CIRCUIT IS LIVE UNLESS THE AREA IS KNOWN TO BE NON-HAZARDOUS.
- D. ALL MODULES USED WITH ACCESSORIES MUST USE R/C (ECBT2) MATING PLUG FOR ALL APPLICABLE MODELS. ALL MATING PLUGS SHALL HAVE SUIT-ABLE RATINGS FOR DEVICE.





NOTE: A 2-meter cable is available for each D-sub module. See the Specifications Chart below.



Specifications Specification Specif				
	ZL-RTB-DB09	ZL-RTB-DB15	ZL-RTB-DB25	
Description*	9-pin male and female D-subs to terminal blocks	15-pin male and female D-subs to terminal blocks	25-pin male and female D-subs to terminal blocks	
Approvals	$\label{eq:File} \textit{File \# E200031 UL, cUL, Class 1, Division 2, Groups A,B,C,D Hazardous Locations, CE, EN 61131-2:2007}$			
UL Voltage Rating**	30VDC			
Maximum Current per Circuit	1A			
Number of Circuits	9	15	25	
Wire Range (Rated Cross Section)**	12-24AWG Solid or Stranded Copper Conductor (2.5mm²)			
Wire Strip Length	0.24-0.27" (6-7mm)			
Screw Torque	4.4 in-lbs (0.5 Nm)			
Surrounding Temperature Range	32 to 140°F (0 to 60°C)			
Terminal Block Contacts	Copper alloy, tin-lead plated			
Dimensions (WxHxD)	1.74" x 3.42" x 2.03" (44.1mm x 86.8mm x 51.6mm)	2.18" x 3.42" x 2.03" (55.4mm x 86.8mm x 51.6mm)	3.50" x 3.42" x 2.03" (88.9mm x 86.8mm x 51.6mm)	
Cable/Wire Clearances	0.5" (12.7mm)			
Mounting Restrictions	None			
Cables (sold seperately)	ZL-DB9-CBL-2	ZL-DB15-CBL-2	ZL-DB25-CBL-2	

<sup>\*</sup>Connecting cables are for internal wiring only. \*\*Use Class 2 Power Supply. Use conductors rated 60°/75°C.





#### RJ12 Feedthrough Module **Installation Instructions**

### **ZL-RTB-RJ12**

#### **DIN Rail Installation** and Removal

To install ZIPLink module, insert upper tab into DIN rail. Note: For cable/wire clearance





**WARNING:** To minimize the risk of potential safety problems, you should follow all applicable local and national codes that regulate the installation and operation of your equipment. These codes vary from area to area and it is your responsibility to determine which codes should be followed, and to verify that the equipment, installation, and operation are in compliance with the latest revision of these codes.

Equipment damage or serious injury to personnel can result from the failure to follow all applicable codes and standards. We do not guarantee the products described in this publication are suitable for your particular application, nor do we assume any responsibility for your product design, installation, or operation.

If you have any questions concerning the installation or operation of this equipment, or if you need additional information, please call Technical Support at 770-844-4200.


This publication is based on information that was available at the time it was printed. At AutomationDirect.com® we constantly strive to improve our products and services, so we reserve the right to make changes to the products and/or publications at any time without notice and without any obligation. This publication may also discuss features that may not be available in certain revisions of the product.


## ▼AUTOMATIONDIRECT®

3505 Hutchinson Road, Cumming GA 30040 1-800-633-0405 www.automationdirect.com


Copyright 2008, Automation Direct.com Incorporated/All Rights Reserved Worldwide










Pin Layout (For Reference Only)





NOTE: A 2-meter cable is available for use with the ZL-RTB-RJ12. See the Specifications Chart below.





Specifications Specification		
Description*	RJ12 Connector module to terminal block	
Approvals	File # E200031 UL, cUL, Class 1, Division 2, Groups A,B,C,D Hazardous Locations, CE, EN 61131-2:2007	
UL Voltage Rating**	30VDC	
Maximum Current per Circuit	1A	
Number of Circuits	6	
Terminal Block Contacts	Copper alloy, tin-lead plated	
Wire Range (Rated Cross Section)**	12-24AWG Solid or Stranded Copper Conductor (2.5mm²)	
Wire Strip Length	0.24-0.27" (6-7mm)	
Screw Torque	4.4 in-lbs (0.5 Nm)	
Surrounding Temperature Range	32 to 140°F (0 to 60°C)	
Dimensions (WxHxD)	1.74" x 3.42" x 2.03" (44.1mm x 86.8mm x 51.6mm)	
Cable/Wire Clearance	0.5" (12.7mm) Required	
Mounting Restrictions	None	
Cable (Sold Seperately)	ZL-RJ12-CBL-2, Standard-reverse 26AWG cable, RJ12 connectors, 2m (6.6ft.)	

<sup>\*</sup>Connecting cables are for internal wiring only.

\*\*Use Class 2 Power Supply. Use conductors rated 60°/75°C.