



# BALANCE keyboard

User Guide







## Box contents

1. Balance Keyboard
2. Wireless Receiver
3. User Guide
4. Two AAA Batteries




## Keyboard Setup



### Step 1:

Remove the back housing and insert AAA batteries.

Remove Wireless Receiver from housing.



### Step 2:

Plug the Wireless Receiver into an open USB port.




### Step 3:

Enjoy using your Balance Keyboard!

## Function and Media Control Keys

- A. Media Control
- B. Application Functions
- C. Interface Functions
- D. Volume Control
- E. Fn Key



## Function and Media Control Keys

Media Control



Back Stop Play/Pause Forward

Application Functions



Calculator Web Mail Settings

Interface Functions



Print Screen Scroll Lock Pause Break Insert

Volume Control



Mute Volume Down Volume Up



Fn Key (Activate F1-F12 functions)

Hold Fn Key with desired function or quickly release Fn Key to activate Fn Lock.

## Connection Troubleshooting

In the event that your Balance Keyboard loses connection, please try the following solutions:

- Make sure the wireless receiver is plugged into a working USB port on your computer. Unplug the receiver and re-insert it after a few seconds.
- Verify that the batteries in the keyboard are fully charged. Remove one battery and re-insert it after a couple of seconds.
- Confirm that the wireless receiver is not too far from the keyboard, or too close to other wireless devices.
- Press the Reset button under the keyboard while the button itself is very close to the wireless receiver.

If trouble persists please consult our online troubleshooting guide at [contourdesign.com](http://contourdesign.com)

For more information please visit:  
[www.contourdesign.com](http://www.contourdesign.com)

Contour Design, Inc.  
10 Industrial Drive  
Windham, New Hampshire 03087, USA  
Phone: (603) 893-4556  
Email: [ergoinfo@contourdesign.com](mailto:ergoinfo@contourdesign.com)

Contour Design Europe A/S  
International House  
Center Boulevard 5  
2300 Copenhagen S., Denmark  
Phone: +45 32 46 11 20  
Email: [info@contour-design.com](mailto:info@contour-design.com)

Tested to comply with FCC standards



contour 