

TAKE THIS CARD TO YOUR OPTICIAN



To get prescription lenses or have your smart glasses adjusted, take your smart glasses and this card to your optician

OPTICIAN GUIDE

PLEASE FOLLOW THE INSTRUCTIONS ON THIS CARD TO MAKE OPTIMAL ADJUSTMENTS.

MAKING ADJUSTMENTS

ADJUSTABLE / NO ELECTRONICS



HEAT OK ON NOSE BRIDGE

ACETATE FRAME FRONT

Heat okay for lens insertion and nose bridge adjustments.



ADJUST TEMPLE TIPS WITHOUT HEAT

TEMPLE TIPS ADJUSTMENTS

Hold firmly on the metal accent near the temple tips with one hand and adjust with the other hand.

NOT ADJUSTABLE / CONTAINS ELECTRONICS



NO HEAT ON ENDPieces OR HINGES



NO HEAT ON TEMPLES

DO NOT ADJUST WITH PLIERS

Pliers will damage internal sensors.

DO NOT APPLY TILT

Does not support pantoscopic tilt.

FULFILLING LENSES



PRESCRIPTION RANGE

Determine appropriate prescription as you would with acetate frames. Our suggested prescription range (spherical equivalent) covers: -8.00 to +4.00. We recommend high index lenses for prescriptions of -5.00 or higher.



EDGE / INSERT / REMOVE

Edge, insert, and remove lenses as you would with acetate frames.



HOT OR COLD MOUNT OK

Frame front lens insertion, apply heat as needed at optician's discretion.

CLEANING SMART GLASSES



NO ULTRASONIC CLEANERS

Do not submerge smart glasses, clean the device with a soft, dry cloth.



NO ALCOHOL SOLUTIONS ON SMART GLASSES

To remove ink from lenses only, apply isopropyl alcohol (70% max) with caution.



SPLASH RESISTANT (IPX4 RATING)

Do not rinse under running water.

Worry Free Lens Installation: Your Smart Glasses with Alexa were designed to be compatible with prescription lenses, just like any other acetate frames. In the unlikely event that your smart glasses break during the installation of prescription lenses, we will replace them. For more information, see www.amazon.com/devicewarranty.



To see more information on how to handle smart glasses and warranty coverage, scan the QR code, or visit amazon.com/SmartGlassesRx.