

BALANCE keyboard

Wireless

Product Manual



Box content

1. Balance Keyboard Wireless
2. Dongle (wireless receiver)
3. USB Extender Cable
4. Two AAA Batteries
5. User Guide



Function and Media Control Keys

- A. Media Control Functions
- B. Application Functions
- C. Interface Functions
- D. Fn Keys*
- E. Risers
- F. Battery compartment and dongle storage
- G. Power Button**

* The Fn key toggles between function [1-12] and media modes. By default the media keys are active.

** The dongle is inserted in the extender cable on delivery.


*** Pull the tab from the battery compartment to turn on the keyboard for the first time.



Start using your keyboard

- 1 Pull the tab from the battery compartment on the underside of the keyboard.
- 2 Insert the extender cable with the dongle in your computer USB port.

Should you loose the connection, please see page 6 for pairing instructions.



Keyboard Tilt

The adjustable legs on the Balance Keyboard have three tilt options:



Positive tilt



Neutral tilt



Negative tilt

Keyboard Shortcuts - Power Button

The power button turns the Balance Keyboard ON/OFF.

When powering the Balance Keyboard ON, the LEDs on the left side of the keyboard will flash from BOTTOM to TOP. When powering OFF, the LEDs will flash from TOP to BOTTOM.

When OFF, pressing keys will not power ON the keyboard. Only the power button turns it ON again.



Keyboard Shortcuts - PC Mode & Mac Mode

Balance Keyboard is a PC keyboard, compatible with Mac. You toggle between Mac mode and PC mode as described here.

Mac Mode

For Mac mode hold Fn + Caps lock and press and release M key.



PC Mode

For PC mode hold Fn + Caps lock and press and release W key.



Keyboard Shortcuts - Pairing Mode

Ctrl + Power buttons starts pairing mode and clears any existing dongle connections.

Balance Keyboard comes with a dongle that has already been paired. If for any reason your Balance Keyboard and dongle become unpaired, use the following instructions to pair your Balance Keyboard to its dongle again.

Remove the extender cable from the computer and insert it to the USB port again. Hold Control and press Power once to pair keyboard and dongle.

Note: Please hold the Power button as close to the wireless receiver as possible during pairing.



Keyboard Shortcuts - Function

Fn + Power buttons toggles between function mode (F1-F12) and media mode as the default setting.

By default, Balance Keyboard comes with function mode set to OFF.

To activate function mode, press the Fn key.

To change the default setting of function mode to ON, press and hold Fn and press the Power button once.

For more information please visit:
www.contour-design.co.uk

Quay House
The Waterfront
Brierley Hill, Dudley
West Midlands, DY5 1XD
United Kingdom
Phone: +45 70 27 02 27
Email: info@contour-design.com

Tested to comply with FCC
and IC standards.



FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IC Statement

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met. This product meets the applicable Industry Canada technical specifications.

Le présent appareil est conforme aux CNR d'Industrie Canada applicable aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement

Warranty

If there is a functional defect due to faulty manufacturing, we will replace the product. This warranty does not cover damage that results from misuse of the product.

Attention!

If you attempt to dismantle the product, you will invalidate your warranty.

contour 