⚠ CAUTION

✕ Don't Connect directly to the **DC24V** power supply, **10mA** upper limit!



✕ Don't Pull the cable with excessive force!!



✕ Don't Contact the switch with angled workpiece!!

*Except angled touch type switches



✕ Don't Push to the stroke end!!

*Except stopper bolt with a built-in switches



GM-T-MSM-E-K002

⚠ CAUTION

✕ Don't Connect directly to the **DC24V** power supply, **10mA** upper limit!



✕ Don't Pull the cable with excessive force!!



✕ Don't Contact the switch with angled workpiece!!

*Except angled touch type switches



✕ Don't Push to the stroke end!!

*Except stopper bolt with a built-in switches



GM-T-MSM-E-K002

⚠ CAUTION

✕ Don't Connect directly to the **DC24V** power supply, **10mA** upper limit!



✕ Don't Pull the cable with excessive force!!



✕ Don't Contact the switch with angled workpiece!!

*Except angled touch type switches



✕ Don't Push to the stroke end!!

*Except stopper bolt with a built-in switches



GM-T-MSM-E-K002

⚠ CAUTION

✕ Don't Connect directly to the **DC24V** power supply, **10mA** upper limit!



✕ Don't Pull the cable with excessive force!!



✕ Don't Contact the switch with angled workpiece!!

*Except angled touch type switches



✕ Don't Push to the stroke end!!

*Except stopper bolt with a built-in switches



GM-T-MSM-E-K002