

Index

A

Allen-Bradley, programming, 5-8

C

Cables

- connections, 2-8
- selection, 2-9
- wiring details, 2-10

Comm port, 1-5

Communications, connections table, 4-5

Configuration

- address, 2-11
- panel, 4-3
- preparation, 4-2
- software, 4-2

Configuring, communications, 4-5

D

Dimensions

- cutout, 2-5
- mounting, 2-5

DirectLOGIC

- communications table, 4-5
- programming, 5-2

E

Environmental specifications, 2-6

F

Frequently Asked Questions, 1-6

I

Indicator Lamps

- flashing, 3-3
- turning on, 3-3

L

Label

- creating, 2-3
- installation, 2-2
- templates, 2-4

Legends, 2-3

M

Memory

- register assignment, 3-4, 3-5
- register definition, 3-4
- register usage, 5-2

Memory Mapping, overview, 3-6

O

OP-Panel

- overview, 1-4
- pushbuttons, 1-4

OP-panel

- configuration mode, 2-11
- features, 3-2
- labels, 2-2

OPEditor

- configuration cable, 2-11
 - configuration software, 4-2
 - installation, 4-3
 - system requirements, 4-3
 - user steps, 4-3
-

Operating Specifications, 2-6

P

Panel

- configuration, 4-3
- cutout dimensions, 2-5
- features, 3-2
- mounting dimensions, 2-5
- overview, 1-4
- set-up, 4-2

Physical Specifications, 2-6

Power Supply

- connections, 1-5, 2-7
- hook-up, 2-7
- requirements, 2-7

Preparing, labels, 2-2

Programming

- Allen-Bradley, 5-8
- examples, 5-2

Pushbuttons, reading status, 3-3

S

Software, creating labels, 2-2

Specification, storage temperature, 2-6

Specifications, 2-6

- communication link, 2-6
- diagnostics, 2-6
- environmental, 2-6
- NEMA rating, 2-6
- power connector, 2-6

T

Technical Support, 1-2

Troubleshooting, 5-12
