

Step 1

Install the Hanger onto the ceiling

Before the installation, you need to find out the type of ceiling at the installing position, whether it is a cement ceiling or a wooden ceiling.
Note: For installation on a wooden ceiling, avoid applying the lag bolt (E) to a decorative beam or a gypsum board.
 Decide the position for the installation, lean the Iron Hanger (A) against the ceiling, and mark the oval holes of the hanger (onto the ceiling) with a pencil.
 Use an electric drill and a drilling bit to drill holes on the marked positions.

Use an electric drill and a drilling bit to drill holes on the marked positions

Note: For a brick-piled masonry wall or cement wall, holes of 10mm diameter and 55mm depth shall be made.

Use an electric drill and a drilling bit to drill holes on the marked positions

Note: For a stud wall, holes of 4.5mm diameter and 55mm depth shall be made.

Step 2

For a wooden ceiling, use screws (E) to tighten the Iron Hanger (A) to the ceiling directly

For a cement ceiling, use the hammer to drive the Plastic Plug (D) into the holes on the ceiling, then, tighten the Iron Hanger (A) to the ceiling with screws (E).

Step 3

Step 4

Step 5

Lock Up

Step 6

Step 7

Step 9-1

Step 9-2

Adjusting the required angle

Cable Management

Length can be adjusted; the shortest length is 127.7mm and the longest is 577.7mm (each 25mm apart).