

Step 1-1 **Masonry Walls or Cement Walls**

Drill a hole at the marked position with an electric drill and drilling bit.

Note: For a brick-piled masonry wall or cement wall, holes of 10mm diameter and 55mm depth shall be made.

Step 1-1 **Stud Walls**

Note: For a stud wall, holes of 4.5mm diameter and 55mm depth shall be made.

Step 1-2 **1 Arm**

Remove the cover

Step 1-3

Fix the Wall mount bracket (F) onto the wall with Lag Bolts (B).

Step 2

6 mm Allen Wrench

Step 1-2 **1 Arm**

Remove the cover

Step 2

Fix the Wall mount bracket (F) onto the wall with Lag Bolts (B).

Step 1-2 **2 Arms**

Remove the cover

Step 1-3

Fix the Wall mount bracket (F) onto the wall with Lag Bolts (B).

Step 2

6 mm Allen Wrench

Step 1-2 **2 Arms**

Remove the cover

Step 2

Fix the Wall mount bracket (F) onto the wall with Lag Bolts (B).

Step 3

Step 4

Do not tighten the screws!

5 mm Allen Wrench

Step 5

Hook

Tighten the monitor screws!

5 mm Allen Wrench

Step 4

Do not tighten the screws!

4-5mm

5 mm Allen Wrench

Step 5

Hook

Tighten the monitor screws!

5 mm Allen Wrench

Step 6

Step 7

Hook

Step 8

5 mm Allen Wrench

Step 9

5 mm Allen Wrench

Step 10

Tilt (Hinge)

2.5 mm Allen Wrench

+35°

-5°

Tilt (Keyboard)

5 mm Allen Wrench

+90°

0°

Torque Adjust

5 mm Allen Wrench

Rotate

Rotate 360°

Rotate 90°

Fix

Arm Swing Adjust

6 mm Allen Wrench

±90°

Cable Management

Hook

Cable Management

Hook

Height Adjust

8 mm 1/4" Drive

+65°

-30°

Cable Management

Hook

⊗ Hole for "Masonry Walls or Cement Walls"
⊗ Hole for "Stud Walls"

